



Manufacturer: ZIRI ELECTRICAL TECHNOLOGY CO.,LTD.
Add: NO.66 DAQIAO ROAD,LIUSHI .WENZHOU,ZHEJIANG PROVINCE.CHINA.
Tel:86-577-27863300
Http:// www.chziri.com

CHZIRI®



ZVF600-G Series Inverter

User's Manual

ZIRI ELECTRICAL TECHNOLOGY CO.,LTD.

All copyrights reserved. shall not be reproduced.

All parts ZVF600-G Series inverter, including software, appearance, circuit board design and user manuals, etc. which are owned ZIRI Electrical Technology Co., Ltd. (hereinafter referred to as the Company) to all. Without obtaining our company's agreement. Any company or individual shall not imitate, copy, and extract. Otherwise the company shall have the right to pursue the responsibility of the parties.

The content that user manual mentioned, just for reference, the software program might change or upgrade. the user manual is also subject to change or upgrade without additional notice. The details for software change and upgrade, please go to our website for checking or contact with our company directly.

Our company has no obligation to undertake any responsibility if there have any error for the content the user manual mentioned.

software version:V1.04

ZIRI ELECTRICAL TECHNOLOGY CO.,LTD.
2021-02

Table of Contents

1. Preface	1
2. Product Introduction	1-4
2.1 Product Inspection Upon Arrival	1
2.2 Model Description	2
2.3 Nameplate Description	2
2.4 Model Type	2
2.5 Model Specifications	3-4
3. Wiring	5-6
3.1 Inverter Basic Wiring Diagram	5
3.2 Main Terminal Description	5
3.3 Control Terminal Description	5-6
4. Keypad and Operating Instruction	7
4.1 Keypad Diagram	7
4.2 Keypad Use	7
5. Detailed function description	8-118
5.1 Function Parameters	8-39
5.2 Detailed function description	40-118
6. Common Fault & Aomaliesand Solutions	119-123
6.1Fault Code and Solutions	119-122
6.2Anomalies and Solutions	122-123
7. Inverter Inspection and Maintenance	124-129
7.1Inspection and Maintenance	124-127
7.2 Replacement of the Inverter Wearing Parts	128-129
7.3 Storage of the Inverter	129
8. Outline Dimension & Installation Dimension	130-131
8.1 Inverter Outline Dimension & Installation Dimension	130-131
9. Quality Warranty	132
9.1 Inverter Quality Warranty	132
Appendix	133-150
Appendix 1: RS485 Communication Protocol	133-148
Appendix 2:Selection List of Peripheral Appliances	149
Appendix 3: Inverter User's Warranty Bill	150

ZVF600-G Series Simple User Manual

1. Preface

Thank you for using ZVF600-G series inverter. The inverter uses high-quality components, and integration of the latest DSP control technology made.

This manual provides instructions for user installation, parameter setting, abnormal diagnosis, troubleshooting, etc.

In order to ensure proper installation and operation of the frequency converter, please read this simple manual carefully before installing, and please keep it and send it to the user of the inverter. For more details, please refer to the company website related to download.

The following is a special note:

- When wiring is performed, be sure to turn off the power.
- The electronic components inside the inverter are particularly sensitive to static electricity, so you can not place foreign objects inside the inverter or touch the main circuit board.
- After turning off the AC power, the digital indicator of the inverter didn't light off. It indicates that there is still high voltage inside the inverter. Do not touch the internal circuit and parts.
- Be sure to properly ground terminal of inverter is correct connect.
- Never connect the inverter output terminals U, V, W to AC power supply.

2. Product Introduction

2.1 Inspection Upon Arrival

The inverter have excellent quality assurance system, Please passed strict test before shipment. and made a crash, shock or other package treatment. But we can not rule out the inverter subject to strong shock or extruded during transportation. Please check and confirm the products as follow when open the package.

① Check whether the case of inverter is deformed or damaged. or the components are damaged or drop off.

② Check the label of the inverter are matched with the product that you ordered.

③ Check whether the items of packing list are complete.

If you find any of the above problems, please contact with our factory immediately.

2.2 Demonstration Of The Model




Fig.2-1 Inverter Model Demonstration

2.3 Specification Label




Fig.2-2 Inverter Label

2.4 Model Type




Fig.2-3 Wall-Mounted Plastic type

2.5 Model Specification

Sheet 2-1 Inverter Model and Specification

Inverter Model (P: Intelligent pump type)	Input Voltage (V)	Rated Output Current (A)	Adaptation motor power(kW)
ZVF600-G0R7T2/S2	220	4.5	0.75
ZVF600-G1R5T2/S2	220	7.0	1.5
ZVF600-G2R2T2/S2	220	10	2.2
ZVF600-G3R7T2	220	16	3.7
ZVF600-G0R7T4	380	2.5	0.75
ZVF600-G1R5T4	380	3.7	1.5
ZVF600-G2R2T4	380	5.0	2.2
ZVF600-G3R0T4	380	6.8	3.0
ZVF600-G4R0T4	380	9.0	4.0
ZVF600-G5R5T4	380	13	5.5
ZVF600-G7R5T4	380	17	7.5

Sheet 2-2 Description Summary for Technical indications

Item		Item Description
Input	Rated voltage&Frequency	Single/Three phase 220VAC. Three phase 380V. 50Hz/60Hz
	Allowable Voltage range	Voltage fluctuate range: -20%~+20% Voltage unbalance rate; < 3%; Frequency fluctuation: ≤ 5%
Output	Rated voltage	Three phase 0~ input AC voltage
	Frequency	0.00~600.00Hz
Basic Function	Frequency accuracy	Digital setting: Max.Frequency × ± 0.01% Analog setting: Max.Frequency × ± 0.2%
	Frequency resolution	Digital setting: 0.01Hz Analog setting: Max.Frequency × 0.1%.
	Starting frequency	0.00~10.00Hz
	Acceleration/deceleration time	0.1~3600 can be set in sequence.
	Carrier frequency	1.0~15.0KHz
	V/F curve	1: linear curve; 2:quadratic; 3:user defined V/F curve
	Automatic energy-saving operationAutomatic energy-saving operation	Auto optimize V/F curve according to the load changes to realize the energy saving operation.
	Built-in PID	This can form a convenient closed-loop control system(CLCs)and is applicable to pressure control,flow control and other process control.
	Operating command	Operation panel control,external terminal control and COM control
	Frequency setting	Keypad potentiometer setting,operation panel ▲▼ setting,analog voltage signal or external potentiometer setting,analog current signal setting,terminal combination setting,485 COM setting and so on.
	Input Signal	Forward/Reverse signal、multi-speed signal、fault signal、reset signal etc
	Output signal	Programmable relay
	Other Function	Over voltage alarm、Rotation speed tracking、Momentary power loss restart、Frequency upper/lower limiting、Acceleration/Deceleration mode can be adjusted、Multi-speed/ program running、Fault auto reset、Rs485 serial communication.
	Protection Function	Input phase loss protection、Over current protection、Overload protection、Over voltage protection、Under voltage protection、Over heat protection etc.
	LED Display	Can display the real time running status of the inverter,monitor parameter,function parameter and fault code and other information of the inverter.
Ambient	Place to be used	Indoor location free from direct exposure to sun light,high humidity or dew condensation, high levels of dust,corrosive gas,explosive gas,inflammable gas,li mist,salt and etc
	Altitude	Below 1000 M
	Ambient Temperature	-10℃ to +45 ℃ (Bare Machine:-10 ℃ to+50 ℃)
	Humidity	20%-90% RH without dew condensation
	Vibration	< 0.5G
	Storage temperature	-20~+60℃
Structure	Protection class	IP54
	Cooling mode	forced air cooling
	installation	Wall mounted

3. Wiring

3.1 Basic Wiring Diagram For Inverter




Fig. 3-1 Basic Wiring Diagram

3.2 Main Circuit Terminals




Fig.3-2 Diagram for Main Circuit Terminal

3.3 Description On Control Circuit Terminals

1. Control circuit terminal are shown in the Fig.3-3.




Fig.3-3 Control Circuit Terminal

2.Function Description on Control circuit Terminals

Sheet 3-1 Function Description on Control circuit Terminals

Type	Terminal Symbols	Function Description	Electrical Specification
Multi-Function Input Terminal	MI1	Valid only when there is a short circuit between MIn(n=1, 2, 3, 4, 5) – GND. The frnctions can be set by the parameter F5.00 –F5.04 separately .	INPUT, Power level signal, Low power level is valid. 5mA
	MI2		
	MI3		
	MI4		
	MI5		
Analog Input Terminal	5V	External analog given power, and GND, AI terminal connected potentiometer, the frequency can be set .	INPUT, 5V DC Voltage
	AI	Analog voltage or current signal input, reference ground is GND	INPUT, 0~5V/10V DC Voltage INPUT, 0~20mA DC Current
Public Port	GND	Signal Public Terminal	
Power connector	+24V	24VDC Power Output (Control Power)	24VDC-100mA
Programmable output terminal	TA	Relay contact output, normal: TA-TB closed, TA-TC disconnect. During operation: TA-TB is disconnected and TA-TC is closed. The function is set by F6.02	Contact Rated Value: NO: 240VAC-3A NC: 240VAC-1A
	TB		
	TC		
Communication Port	485+	Communication Signal Positive	
	485-	Communication Signal Negative	

4. Keypad and Operating Instruction

4.1 Keypad Diagram





Fig.4-1 E-600G Keypad schematic

4.2 Keypad Use

Change the function code parameter value (change F0.08 acceleration time parameter value from 10.0s to 20.0s)



5. Detailed function description

5.1 Function Parameters

- The marked “√” indicates the setting value of parameter can be modified no matter when the inverter is shut down or running.
- The marked “X” indicates the setting value of parameter can be modified only when the inverter is shut down, and can not be modified when the inverter is running.
- The marked “_” indicates the parameter can be displayed only and can not be modified.

5.1.1 F0 Group Basic function

Code	Name	Setting Range	Min.Unit	Factory setting	Running Modification
F0.00	Speed control mode	0: NO PG vector control 1: V/F control 2: Torque control (NO PG Vector Control) 3.Reserve 4.PG vector control	1	1	×
F0.01	Running command channel	0: Keyboard command channel 1: Terminal command channel 2:Communication command channel	1	0	×

5.1.1 F0 Group Basic function(Continued)

Code	Name	Setting Range	Min.Unit	Factory setting	Running Modification
F0.02	Keyboard and terminal UP/Down setting	0: Valid , save the parameters when the inverter is powered off 1: Valid .the value can not be saved when the inverter is powered off 2: UP/DOWN setting is invalid 3: Valid during running ,clear when the inverter stops . 4.Valid when F0.03=0.	1	0	✓
F0.03	Frequency command selection	0: Keyboard or encoder setting 1: AI 2: Reserved 3: Reserved 4: keyboard potentiometer setting 5: Water supply PID control setting 6: Remote communication setting 7: Reserved 8: Reserved 9: Reserved 10: Reserved 11: Reserved 12: Common PID control setting	1	0	✓
F0.04	Maximum output frequency .	10.00~600.00Hz	0.01Hz	50.00Hz	×
F0.05	Upper limit frequency	F0.06~F0.04 (Max. Frequency)	0.01Hz	50.00Hz	✓
F0.06	Lower limit frequency	0.00~F0.05 (Running frequency upper limit)	0.01Hz	0.00Hz	✓

5.1.1 F0 Group Basic function(Continued)

Code	Name	Setting Range	Min.Unit	Factory setting	Running Modification
F0.07	keypad setting frequency	0.00~F0.04 (Max. Frequency)	0.01Hz	50.00Hz	✓
F0.08	Acceleration time 1	0.1~3600.0s	0.1s	Depend on the model	✓
F0.09	Deceleration time 1	0.1~3600.0s	0.1s	Depend on the model	✓
F0.10	Running direction selection	0: Forward (the default running direction) 1: Reverse 2: Forbid reverse	1	0	×
F0.11	Carrier frequency	1.0~15.0kHz	0.1kHz	Depend on the model	✓
F0.12	Motor parameters autotuning	0: No action 1: Rotation autotuning 2: Static autotuning	1	0	×
F0.13	Restore parameters	0: No action 1: Restore the default value Restore all parameters F0~Fd to factory setting except F2 group. 2: Clear fault records Inverter clear all fault records. 3: Restore the default value to 380V/60Hz. 4: Restore the default value to 440V/50Hz. 5: Restore the default value to 440V/60Hz.	1	0	×
F0.14	AVR Function	0: Disable 1: Enable all the time 2: Disabled during deceleration	1	0	✓

5.1.1 F0 Group Basic function(Continued)

Code	Name	Setting Range	Min.Unit	Factory setting	Running Modification
F0.15	Reserved				—
F0.16	Reserved				—
F0.17	Parameter Locked	0: Invalid 1: Valid	1	0	×
F0.18	Acc/Dec Mode Selection	0: Linear 1: S Curve	1	0	×
F0.19	Temperature alarm switch	0: Invalid 1: Valid	0	0	✓
F0.20	Alarm temperature value				

5.1.2 F1 Group start and stop control

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F1.00	Start Mode	0: Start directly 1: DC braking and start 2: Speed tracking starting	1	0	×
F1.01	Direct starting frequency	0.00~50.00Hz	0.01Hz	1.50Hz	✓
F1.02	Starting frequency maintain time	0.0~50.0s	0.1s	0.0s	✓
F1.03	DC braking current before start	0.0~150.0%	0.1%	0.0%	✓
F1.04	DC braking time before start	0.0~50.0s	0.1s	0.0s	✓
F1.05	Stop mode	0: Ramp to stop 1: Coast/Free stop 2: Deceleration stop +Free stop	1	0	✓
F1.06	Starting frequency of DC braking at stopping	0.00~F0.04 (Max.frequency)	0.01Hz	0.00Hz	✓
F1.07	Braking wait time at stopping	0.0~50.0s	0.1s	0.0s	✓

5.1.2 F1 Group start and stop control(Continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F1.08	DC braking current at stopping	0.0~150.0%	0.1%	0.0%	✓
F1.09	DC braking time at stopping	0.0~50.0s	0.1s	0.0s	✓
F1.10	Dead time of FWD/REV	0.0~3600.0s	0.1s	0.0s	✓
F1.11	Terminal running protection selection when power on	0: Command invalid when powered on 1: Command valid when powered on	1	0	✓
F1.12	Input/Output terminal polarity selection	0x000~0x7FF	1	0x000	✓
F1.13	Power off Restart Mode Selection	0.Disabled 1.Regular Start 2.Start with rotary tracing	1	0	×
F1.14	Power Cut Restart Wait Time	0.0-20.0S	0.1	0.5S	×

5.1.3 F2 Group Motor parameters

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F2.00	Inverter Type	0: G Type	1	Depend on model	×
F2.01	Motor rated power	0.4～700.0kW	0.1kW	Depend on model	×
F2.02	Motor rated frequency	0.01～600.00Hz	0.01Hz	50.00Hz	×
F2.03	Motor rated rotate speed	0～3600rpm	1rpm	Depend on model	×
F2.04	Motor rated voltage	0～460V	1V	Depend on model	×
F2.05	Motor rated current	0.1～2000.0A	0.1A	Depend on model	×
F2.06	Motor stator resistance	0.001～65.535Ω	0.001Ω	Depend on model	√
F2.07	Motor rotor resistance	0.001～65.535Ω	0.001Ω	Depend on model	√
F2.08	Motor leakage inductance	0.1～6553.5mH	0.1mH	Depend on model	√
F2.09	Motor mutual inductance	0.1～6553.5mH	0.1mH	Depend on model	√
F2.10	Motor Current without load	0.01～655.35A	0.01A	Depend on model	√

5.1.4 F3 Group Vector control

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F3.00	Proportional gain 1 of speed loop	0~10000	1	15	√
F3.01	Integration time 1 of speed loop	0.01~100.00s	0.01s	2.00s	√
F3.02	Low switching point frequency	0.00~F3.05	0.01Hz	5.00Hz	√
F3.03	Proportional gain 2 of speed loop	0~10000	1	10	√
F3.04	Integration time 2 of speed loop	0.01~100.00s	0.01s	3.00s	√
F3.05	High switching point frequency	F3.02~F0.04 (Max. Frequency)	0.01Hz	10.00Hz	√
F3.06	Slip compensation rate of VC	50~200%	1%	100%	√
F3.07	Torque upper-limit setting	0.0~200.0% (Inverter rated current)	0.1%	150.0%	√
F3.08	Torque dynamic friction coefficient	0.000~1.000	0.001	0.125	√
F3.09	Empty load current compensation coefficients	0.000~9.999	0.001	0.800	√
F3.10	Torque static friction coefficient	0.00-10.00	0.001	2.00	√

5.1.5 F4 Group V/F Control

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F4.00	V/F Curve Setting	0: Linear V/F Curve 1: Square V/F Curve 2: User Setting V/F Curve 3.1.25power V/F Curve 4.1.7 power V/F Curve 5. 3 power V/F Curve 6. 4 power V/F Curve	1	0	×
F4.01	Torque Boost	0.0%: (auto) 0.1~30.0%	0.1%	0.0%	√
F4.02	Torque boost cutoff	0.0~50.0% (Relative to the rated motor frequency)	0.1%	20.0%	×
F4.03	V/F Slip compensation limit	0.0~100.0%	0.1%	0.0%	√
F4.04	Auto energy saving selection	0: Disable 1: Enabled	1	0	×
F4.05	Reserved				—
F4.06	V/F Frequency Value F1	0-F4.08	0.01Hz	12.5Hz	√
F4.07	V/F Voltage Value V1	0-F4.09	0.01%	25.00%	√
F4.08	V/F Frequency Value F2	F4.06-F4.10	0.01Hz	25.00Hz	√
F4.09	V/F Voltage Value V2	F4.07-F4.11	0.01%	50.00%	√
F4.10	V/F Frequency Value F3	F4.08-F0.05	0.01Hz	37.50Hz	√
F4.11	V/F Voltage Value V3	F4.09-100.00%	0.01%	75.00%	√
F4.12	Low voltage protection selection	0: Enabled 1: Disable	1	0	√

5.1.6 F5 Group Input terminal

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F5.00	MI1 terminal function selection	0: No function 1: Forward running 2: Reverse running 3: 3-Wire running control 4: Jog forward control 5: Jog reverse control 6: Coast to stop 7: Reset fault; 8: External fault input 9: Frequency UP command (UP) 10: Frequency DOWN command(DOWN) 11: Clear frequency UP/DOWN 12: Multi-step speed terminal 1 13: Multi-step speed terminal2 14: Multi-step speed terminal 3 15: Multi-step speed terminal 4 16: Acceleration and deceleration time selection 17: PID control pause 18: Traverse frequency pause (stop at the current frequency) 19: Traverse frequency reset (return to the centre frequency). 20: Acceleration and deceleration prohibition 21: Disable torque control 22: Clear frequency acc.and dec. settings 23: DC braking when stopping 24: External pulse input 25: Reserved 26: Frequency switch to AI 27:Reserved 28: Coast to stop control 29: Running command switch to terminal 30:PLC reset 31: PLC input 32: Count input 33. Frequency switch to the combination 34: Count clear	1	1	×
F5.01	MI2 terminal function selection		1	2	×
F5.02	MI3 terminal function selection		1	7	×
F5.03	MI4 terminal function selection		1	0	×
F5.04	MI5 terminal function selection		1	0	×
F5.05	Reserved				—
F5.06	Reserved				—
F5.07	Reserved				—

5.1.6 F5 Group Input terminal(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F5.08	ON/OFF filter times	1~100	1	5	√
F5.09	Terminal control running mode	0: 2-wire control mode 1 1: 2-wire control mode 2 2: 3-wire control mode 1 3: 3-wire control mode 2	1	0	×
F5.10	UP/DOWN terminal change speed rate	0.01~50.00Hz/s	0.01Hz/s	0.50Hz/s	√
F5.11	AI lower limit	0.00~10.00V	0.01V	0.00V	√
F5.12	AI lower limit corresponding setting	-100.0~100.0%	0.1%	0.0%	√
F5.13	AI upper limit	0.00~10.00V	0.01V	10.00V	√
F5.14	AI upper limit corresponding setting	-100.0~100.0%	0.1%	100.0%	√
F5.15	AI input filter time	0.00~10.00s	0.01s	0.10s	√
F5.16 ~F5.25	Reserved				—
F5.26	Center voltage hysteresis loop width	0.00~10.00V	0.01V	0.15V	√
F5.27	Cooling Fan control	0:Auto operation : The fan will run when the inverter starts . and will stop when the inverter stops. 1:The cooling fan is running when the inverter energized on .	1	0	×

5.1.7 F6 Group Output terminal

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F6.00	Reserved	0: No output 1: Forward running 2: Reverse running 3: Fault output 4: Frequency level detection FDT output	1	-	√
F6.01	Reserved	5: frequency reached 6: Zero speed running 7: Upper limit frequency reached 8: Lower limit frequency reached 9:Running 10: PLC stage completed 11:PLC cycle completed		-	√
F6.02	Relay output selection	12: Overload Pre-alarm 13: Specified count value reached 14;Setting count value reached 15: Ready for operation 16:Under load output		3	√
F6.03 ~F6.16	Reserved				-
F6.17	Relay delay closing time	0.1~3600.0s	0.1s	0.0s	√
F6.18	Relay delay disconnect time	0.1~3600.0s	0.1s	0.0s	√
F6.19 ~F6.22	Reserved				-

5.1.8 F7 Group Human-machine interface

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F7.00	The user password	0~65535	1	0	✓
F7.01	The initial selection when Power on	LED Unit's Place、Decade: Running status display options 0x00-0x1F LED hundred's place、Thousand place: Stop status display options 0x00-0x0c	1	0x0000	—
F7.02	Parameter Copy	0: Invalid 1:The parameters will download from the control board to the keypad. 2:The parameters will download from the keypad to the control board (Includes motor parameters) 3:Reserve 4:The parameters will download from the keypad to the control board . (Without motor parameters).			—
F7.03	REV/JOG function selection	0: Jog operation 1: FWD/REV switching 2: Clear UP/DOWN setting 3:Reverse Running 4:Fast search	1	0	×
F7.04	STOP/RESET key stop function selection	0: Valid when keypad control 1: Valid when keypad or terminal control 2: Valid when keypad or communication control 3: Always valid	1	0	✓
F7.05	Gauge Range Decimal Place	0-3	1	2	✓

5.1.8 F7 Group Human-machine interface(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F7.06	Running state display parameter selection 1	0~0xFFFF BIT0: Running frequency BIT1: Setting frequency BIT2: DC bus voltage BIT3: Output voltage BIT4: Output current BIT5: running rotation speed BIT6: output power BIT7: output torque BIT8: PID setting BIT9: PID feedback BIT10: Input terminal state BIT11: Output terminal state BIT12: Analog AI Setting BIT13: Reserved BIT14: The current step of multi-step BIT15: Torque setting value	1	0x00FF	√
F7.07	Running state display parameter selection 2	0-0X3 BIT0: Count value BIT1: Linkage proportion coefficient BIT2: PLC average speed BIT3: The Current speed of PLC. BIT4: The current running remaining time of PLC .	1	0x0	√
F7.08	Stop state display parameter selection	1~0x1FFF BIT0: setting frequency BIT1: DC bus voltage BIT2: Input terminal state BIT3: Output terminal state BIT4: PID setting value BIT5: PID feedback value BIT6: Analog AI value BIT7: Reserved BIT8: The current step of multi-step BIT9: Torque setting value BIT10: Input AC voltage BIT11: Count Value BIT12: Linkage proportion coefficient BIT13: PLC average speed BIT14: The Current speed of PLC BIT15: The current running remaining time of PLC.	1	0x40F	√

5.1.8 F7 Group Human-machine interface(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F7.09	IGBT module temperature	0~100.0℃	0.1℃		—
F7.10	Software version	0.00~99.9	1.00		—
F7.11	Accumulated running time	0~65535h	1h	0	—
F7.12	Runtime password setting	0~65535	1	0	x
F7.13	Runtime setting	0~65535h	1h	0	x
F7.14	The previous two fault type	0~29 0: No fault (nonE) 1: over current when acceleration (ocA) 2: over current when deceleration (ocd) 3: over-current when constant speed running (ocn) 4: Over-voltage when acceleration (ovA) 5: over-voltage when deceleration (ovd) 6: Over-voltage when constant running (ovn) 7: over-voltage when stopping (ovS) 8: DC bus under voltage (Lv)			—

5.1.8 F7 Group Human-machine interface(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F7.15	The previous fault type	9: Input phase failure (LP) 10: Output short circuit (SC) 11: inverter overheat (OH1) 12: Motor overload (OL1) 13: Inverter overload (OL2) 14: External fault (EF) 15: RS485 communication fault CE-1) 16: Reserved 17: Current detection fault (ItE)			-
F7.16	The current fault type	18: keypad communication fault (CE-4) 19: Autotuning fault (tE) 20: EEPROM fault (EEP) 21: PID feedback fault (PIDE) 22~24: Reserved 25: dCE 26~27: Reserved 28: Output phase failure (SPO) 29: Reserved			-
F7.17	The current fault running frequency	0.00~600.00Hz	0.01Hz		-
F7.18	The current fault output current	0.1~3000.0A	0.1A		-
F7.19	The current fault DC bus voltage	0~1000V	1V		-
F7.20	The current fault temperature	0-100.00℃	0.1℃		-
F7.21	The current fault input terminal state	0~0xFFFF	1	0	-
F7.22	The current fault output terminal state	0~0xFFFF	1	0	-

5.1.9 F8 Group-Enhanced function

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F8.00	Acceleration time 2	0.1~3600.0s	0.1s	Depend on the model	✓
F8.01	Deceleration time 2	0.1~3600.0s	0.1s	Depend on the model	✓
F8.02	Jog running frequency	0.00~F0.04 (Max.frequency)	0.01Hz	5.00Hz	✓
F8.03	Jog acceleration time	0.1~3600.0s	0.1s	Depend on the model	✓
F8.04	Jog deceleration time	0.1~3600.0s	0.1s	Depend on the model	✓
F8.05	Skip frequency	0.00~F0.04 (Mex.frequency)	0.01Hz	0.00Hz	✓
F8.06	Skip frequency bandwidth	0.00~F0.04 (Max.frequency)	0.01Hz	0.00Hz	✓
F8.07	Traverse amplitude	0.0~100.0% (Relative to the setting frequency)	0.1%	0.0%	✓
F8.08	Jitter frequency bandwidth	0.0~50.0% (Relative to the traverse amplitude)	0.1%	0.0%	✓
F8.09	Rise time of traverse	0.1~3600.0s	0.1s	5.0s	✓
F8.10	Fall time of traverse	0.1~3600.0s	0.1s	5.0s	✓
F8.11	Fault auto reset times	0~9999	0	0	✓
F8.12	Fault reset interval time	0.1~100.0s	0.1s	1.0s	✓
F8.13	FDT Level	0.00~F0.04(Max.frequency)	0.01Hz	50.00Hz	✓
F8.14	FDT lag	0.0~100.0% (FDT level)	0.1%	5.0%	✓
F8.15	Frequency arrival detecting range	0.0~100.0% (Max.frequency)	0.1%	0.0%	✓

5.1.9 F8 Group-Enhanced function(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F8.16	Energy braking threshold voltage	380V Series : 115.0~140.0% (Standard DC bus voltage)	0.1%	125.0%	✓
		220V Series : 115.0~140.0% (Standard DC bus voltage)	0.1%	115.0%	✓
F8.17	Coefficient of rotation speed	0.1~999.9% Actual mechanical speed=120* output frequency *F8.17/Number of poles of motor .	0.1%	100.0%	✓
F8.18	Energy braking output starting value	0-100%	1%	0%	✓
F8.19	Over load/Under pre-alarm detection selection	LED bit, overload pre-alarm detection selection 0: No detection 1: Running Detection 2: Constant speed detection LED ten digit, overload pre-alarm action selection 0: No alarm, continue running 1: OL3 alarm, stop running LED Hundred digit, under load pre-alarm detection selection 0: No detection 1: Under load when Running Detection 2: Under load when Constant speed detection LED Thousand digit, under load pre-alarm action selection 0: No Alarm. Continue running 1: UL4 Alarm. stop running.	1	00	✓
F8.20	Overload pre-alarm level	0.0~150.0%	0.1%	130.0%	✓
F8.21	Overload detection time	0.0~6500.0s	0.1s	5.0s	✓
F8.22	The decrease rate of drop control frequency	0.00~15.00%	0.01%	0.00%	✓
F8.23	ENA Mode and Fan control	Units digit 0: ENA OFF 1: ENA ON Decade: 0: Fan start working 1: Fan couldn't work below 0 °C	00	00	✓
F8.24	The proportional gain of ENA frequency increases	0~100	0.00	0.10	✓
F8.25	ENA Integration time	0.01~100	0.01	0.10	✓

5.1.10 F9 Group PID control

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F9.00	PID given source selection	0: Keypad (set by F9.01) 1: Analog channel AI given 2: Reserved 3: Remote communication given 4: Multi-step speed given 5: keyboard direct given	1	0	✓
F9.01	Keyboard preset PID given	0.0~F9.16	0.01MPa	0.00MPa	✓
F9.02	PID feedback source selection	0: Analog channel AI feedback 1: Reserved 2: Reserved 3: Remote communication feedback	1	0	✓
F9.03	PID output characteristics selection	0: PID output is positive 1: PID output is negative	1	0	✓
F9.04	Proportional gain K (Kp)	0.00~100.00	0.01	1.00	✓
F9.05	Integral time Ti (Ti)	0.01~100.00s	0.1s	0.10s	✓
F9.06	Differential time Td (Td)	0.00~100.00s	0.1s	0.00s	✓
F9.07	Sample cycle T (T)	0.01~100.00s	0.1s	0.10s	✓
F9.08	PID control bias limit	0.0~100.0%	0.1%	0.0%	✓

5.1.10 F9 Group PID control(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
F9.09	Feedback lost detecting value	0.0~100.0%	0.1%	0.0%	√
F9.10	Feedback lost detecting time	0.0~3600.0s	0.1s	1.0s	√
F9.11	Feedback gain	0~200%	0.1%	100%	√
F9.12	Awakening threshold Width	0.0~F9.16	0.01 MPa	0.50 MPa	√
F9.13	Awakening threshold detection time	0.00~360.00s	0.01s	1.00s	√
F9.14	Sleep Frequency	0.00~F0.04 (Maximum output frequency)	0.01	30.00Hz	√
F9.15	Sleep Frequency Detection time	0.0~360.00s	0.01S	1.00S	√
F9.16	The gauge range	0.00~20.00MPa	0.01 MPa	20.00MPa	√
F9.17	PID preset frequency	0.00~F0.05 (Running frequency upper limit)	0.01Hz	0.00Hz	√
F9.18	Preset frequency maintain time	0.00~360.00s	0.01s	0.00s	√

5.1.11 FA Multi- step speed control

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FA.00	PLC Mode	LED Unit's Place : PLC running mode selection 0: invalid 1: single circulation 2: continuous circulation 3: single circulation keep the final value . LED Decade;PLC input selection 0: automatic control 1: Terminal Control LED Hundreds place : PLC breakpoints recovery options 0: Restart from the first stage frequency. 1: Restart from running frequency . which is saved before the sunning is breaking . 2: Restart from setting frequency when running is break. PLC Thousands place: PLC power failure save selection. 0: Non-save after power off 1: save after power off	1	0000	√
FA.01	Multi-step speed 1	F0.06-F0.04	0.01Hz	0.00Hz	√
FA.02	Multi-step speed 2	F0.06-F0.04	0.01Hz	0.00Hz	√
FA.03	Multi-step speed 3	F0.06-F0.04	0.01Hz	0.00Hz	√
FA.04	Multi-step speed 4	F0.06-F0.04	0.01Hz	0.00Hz	√

5.1.11 FA Multi- step speed control(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FA.05	Multi-step speed 5	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.06	Multi-step speed 6	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.07	Multi-step speed 7	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.08	Multi-step speed 8	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.09	Multi-step speed 9	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.10	Multi-step speed 10	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.11	Multi-step speed 11	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.12	Multi-step speed 12	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.13	Multi-step speed 13	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.14	Multi-step speed 14	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.15	Multi-step speed 15	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.16	Multi-step speed 16	F0.06-F0.04	0.01Hz	0.00Hz	✓
FA.17	Unit of PLC Running time	0:Second(s) 1: Minute(min)	1	0	✓

5.1.11 FA Multi- step speed control(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FA.18	Curve selection	0: Mode 1 :Linear Operation 1: Mode 2(No wait time) Gradual Operation	1	0	√
FA.19	Multi-speed direction source selection	0: External Control 1: Control itself	1	0	√
FA.20	PLC Accel/Decel Time 1	0.01~3600.0s	0.1S	20.0S	√
FA.21	PLC Accel/Decel Time 2	0.01~3600.0s	0.1S	20.0S	√
FA.22	PLC Accel/Decel Time 3	0.01~3600.0s	0.1S	20.0S	√
FA.23	PLC Accel/Decel Time 4	0.01~3600.0s	0.1S	20.0S	√
FA.24	PLC Accel/Decel Time 5	0.01~3600.0s	0.1S	20.0S	√
FA.25	PLC Accel/Decel Time 6	0.01~3600.0s	0.1S	20.0S	√
FA.26	PLC Accel/Decel Time 7	0.01~3600.0s	0.1S	20.0S	√
FA.27	PLC Accel/Decel Time 8	0.01~3600.0s	0.1S	20.0S	√
FA.28	Acceleration Selection 1	Unit's Place: Multi-Speed 1 FA.20-FA.27. Decade : Multi-Speed 2 FA.20-FA.27 Hundreds place: Multi-Speed 3 FA.20-FA.27 Thousands place: Multi-Speed 4 FA.20-FA.27	1	0x1111	√

5.1.11 FA Multi- step speed control(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FA.29	Acceleration Selection 2	Unit's Place : Multi-Speed 5 FA.20-FA.27 Decade : Multi-Speed 6 FA.20-FA.27 Hundreds place : Multi-Speed 7 FA.20-FA.27 Thousands place : Multi-Speed 8 FA.20-FA.27)	1	0x1111	✓
FA.30	Acceleration Selection 3	Unit's Place : Multi-Speed 9 FA.20-FA.27 Decade: Multi-Speed10 FA.20-FA.27 Hundreds place : Multi-Speed 11 FA.20-FA.27 Thousands place : Multi-Speed 12 FA.20-FA.27	1	0x1111	✓
FA.31	Acceleration Selection 4	Unit's Place : Multi-Speed 13 FA.20-FA.27 Decade: Multi-Speed 14 FA.20-FA.27 Hundreds place : Multi-Speed 15 FA.20-FA.27 Thousands place : Multi-Speed 16 FA.20-FA.27	1	0x1111	✓
FA.32	Deceleration Selection 1	Unit's Place : Multi-Speed 1 FA.20-FA.27 Decade: Multi-Speed 2 FA.20-FA.27 Hundreds place : Multi-Speed 3 FA.20-FA.27 Thousands place : Multi-Speed4 FA.20-FA.27	1	0x1111	✓

5.1.11 FA Multi- step speed control(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FA.33	Deceleration Selection 2	Unit's Place : Multi-Speed 5 FA.20-FA.27 Decade: Multi-Speed 6 FA.20-FA.27 Hundreds place : Multi-Speed 7 FA.20-FA.27 Thousands place : Multi-Speed 8 FA.20-FA.27	1	0x1111	✓
FA.34	Deceleration Selection 3	Unit's Place : Multi-Speed 9 FA.20-FA.27 Decade: Multi-Speed 10 FA.20-FA.27 Hundreds place : Multi-Speed 11 FA.20-FA.27 Thousands place : Multi-Speed 12 FA.20-FA.27	1	0x1111	✓
FA.35	Deceleration Selection 4	Unit's Place : Multi-Speed 13 FA.20-FA.27 Decade: Multi-Speed 14 FA.20-FA.27 Hundreds place : Multi-Speed 15 FA.20-FA.27 Thousands place : Multi-Speed 16 FA.20-FA.27	1	0x1111	✓
FA.36	Direction Selection 1	Unit's Place : Multi-Speed 1 (0-1) 0:Forward 1:Reverse Decade: Multi-Speed 2 (0-1) 0:Forward 1:Reverse Hundreds place: Multi-Speed 3 (0-1) 0:Forward 1:Reverse Thousands place: Multi-Speed 4 (0-1) 0:Forward 1:Reverse	1	0x0000	✓

5.1.11 FA Multi- step speed control(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FA.37	Direction Selection 2	Unit's Place : Multi-Speed 5 (0-1) 0:Forward 1:Reverse Decade:: Multi-Speed 6 (0-1) 0:Forward 1:Reverse Hundreds place: Multi-Speed 7 (0-1) 0:Forward 1:Reverse Thousands place: Multi-Speed 8 (0-1) 0:Forward 1:Reverse	1	0x0000	✓
FA.38	Direction Selection 3	Unit's Place : Multi-Speed 9 (0-1) 0:Forward 1:Reverse Decade:: Multi-Speed 10 (0-1) 0:Forward 1:Reverse Hundreds place: Multi-Speed 11 (0-1) 0:Forward 1:Reverse Thousands place: Multi-Speed 12 (0-1) 0:Forward 1:Reverse	1	0x0000	✓
FA.39	Direction Selection 4	Unit's Place : Multi-Speed 13 (0-1) 0:Forward 1:Reverse Decade:: Multi-Speed 14 (0-1) 0:Forward 1:Reverse Hundreds place: Multi-Speed 15 (0-1) 0:Forward 1:Reverse Thousands place: Multi-Speed 16 (0-1) 0:Forward 1:Reverse	1	0x0000	✓
FA.40	PLC Running Time 1	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.41	PLC Running Time 2	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.42	PLC Running Time 3	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓

5.1.11 FA Multi- step speed control(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FA.43	PLC Running Time 4	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.44	PLC Running Time 5	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.45	PLC Running Time 6	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.46	PLC Running Time 7	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.47	PLC Running Time 8	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.48	PLC Running Time 9	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.49	PLC Running Time 10	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.50	PLC Running Time 11	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.51	PLC Running Time 12	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.52	PLC Running Time 13	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.53	PLC Running Time 14	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.54	PLC Running Time 15	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓
FA.55	PLC Running Time 16	0.0-6553.5 S(Min)	0.1S (min)	0.0S (Min)	✓

5.1.12 Fb Protection function

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
Fb.00	Motor overload protection	0: Disable. 1: normal motor (with low speed compensation) 2: variable frequency motor (without low speed compensation)	1	2	×
Fb.01	Motor overload protection current	20.0~120.0% (Motor rated current)	0.1%	100.0%	√
Fb.02	Momentary power drop frequency point	70.0~110.0% (Standard bus voltage)	0.1%	80.0%	√
Fb.03	Momentary power drop frequency rate of decline	0.00~F0.04 (Max.frequency)	0.01Hz	0.00Hz	√
Fb.04	Over-voltage stall protection	0: Disable 1: Enable	1	1	√
Fb.05	Over-voltage stall protection voltage	110~150% (380V Series) 110~150% (220V Series)	1%	120%	√
Fb.06	Auto limiting current threshold	20~200%	1%	G Series:160% P Series:130%	√
Fb.07	Frequency decrease rate when current limiting	0.00~100.00Hz/s	0.01Hz/s	10.00Hz/s	√
Fb.08	Input phase loss protection selection	0: Invalid 1: software detect is valid 2: hardware detect is valid	1	Depends on the model	√
Fb.09	Under load protection current	0~150.0	0.1%	0.0%	√
Fb.10	Under load protection Time	5.0~6500.0	0.1s	5.0s	√

5.1.13 Fc Group communication parameters

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FC.00	Local address	1~247, 0 is broadcast address	1	1	√
FC.01	aud rate selection	0: 1200bps 3: 9600bps 1: 2400bps 4: 19200bps 2: 4800bps 5: 38400bps	1	4	√
FC.02	Data bit check setting	0: No parity (N, 8, 1) for RTU 1: Even parity (E, 8, 1) for RTU 2: Odd parity (O, 8, 1) for RTU 3: No parity (N, 8, 2) for RTU 4: Even parity (E, 8, 2) for RTU 5: Odd parity (O, 8, 2) for RTU 6: No parity (N, 7, 1) for ASCII 7: Even parity (E, 7, 1) for ASCII 8: Odd parity (O, 7, 1) for ASCII 9: No parity (N, 7, 2) for ASCII 10: Even parity (E, 7, 2) for ASCII 11: Odd parity (O, 7, 2) for ASCII 12: No parity (N, 8, 1) for ASCII 13: Even parity (E, 8, 1) for ASCII 14: Odd parity (O, 8, 1) for ASCII 15: No parity (N, 8, 2) for ASCII 16: Even parity (E, 8, 2) for ASCII 17: Odd parity (O, 8, 2) for ASCII	1	1	√
FC.03	Communication answer delay time	0~200ms	1ms	5ms	√
FC.04	Communication timeout fault time	0.0 (Odd parity) , 0.1~200.0s	0.1s	0.0s	√

5.1.13 Fc Group communication parameters(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
FC.05	Communication error action	0: Alarm and coast to stop 1: Do not alarm and keep running 2: Do not alarm and stop at the stopping method(only for communication control mode) 3: Do not alarm and stop at the stopping method (for all communication control modes)	1	1	√
FC.06	Response action	0: Response to reading and writing 1: No response to writing	1	0	√
FC.07	Communication parameters address mode	0: group mode 1: Sequential mode	1	0	√
FC.08	Linkage proportion coefficient	0.01~10.00	0.01	1.00	√
FC.09	Linkage proportion source selection	0: Keypad or Encoder Setting (FC.08) 1: Annlog AI setting 2: Reserved 3: Multi-stage setting 4: Keyboard or encoder direct setting	1	0	√

5.1.14 Fd Group Supplementary function

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
Fd.00	Low-frequency threshold of restraining oscillation	0~500	1	5	✓
Fd.01	High-frequency threshold of restraining oscillation	0~500	1	5	✓
Fd.02	Amplitude of restraining oscillation	0~100	1	10	✓
Fd.03	Threshold high-low frequency of restraining oscillation	0.00~F0.04 (Max.frequency)	0.01Hz	12.50Hz	✓
Fd.04	Restrain oscillation	0: Enable 1: Diable	1	1	✓
Fd.05	PWM Selection	0: PWM mode 1 1: PWM mode 2 2: PWM mode 3	1	0	×
Fd.06	Torque setting mode selection	0: Keypad setting torque (corresponding to Fd.07) 1: Analog AI setting torque (100% compared to 2 times of inverter rated current) 2: Reserved 3: Reserved 4: multi-stage torque setting (same 1) 5: Remote communication setting torque .(same as 1)	1	0	✓

5.1.14 Fd Group Supplementary function(continued)

Code	Name	Factory setting	Min.Unit	Factory setting	Running Modification
Fd.07	Keypad torque setting	-200.0~200.0% (the rated current of inverter)	0.1%	50.0%	√
Fd.08	Upper limit frequency source selection	0: Keypad setting upper limit frequency (F0.05) 1: Analog AI setting upper limit frequency (100% corresponds to the maximum frequency) 2: Reserved 3: Multi-step setting of upper limit frequency(same as 1) 4: Remote communication setting upper limit frequency (same as 1)	1	0	√
Fd.09	Auto current limiting selection	0: Enabled when constant speed 1: Disabled when constant speed	1	0	√
Fd.10	Lower limit frequency running mode	0: lower limit frequency running 1: zero frequency running and DC braking .	1	0	×
Fd.11	Zero-frequency running braking current	0.0~150.0%	0.1%	0.0%	√

5.2 Detailed function description

F0 Group-Basic function

F0.00 Speed control mode

Setting Range: 0~3

Factory setting : 1

This function is used to select the control mode of the inverter.

0: NO PG vector control

Sensorless vector control(SVC).It means open-loop vector contro, applied to occasions without PG,high-performance general-purpose , an inverter can drive a motor .

1: V/F Control

It's suitable for the application with low accuracy control ,low frequency torque . an inverter can drive multi motors .

2: Torque control

It is suitable for the plication with low accuracy torque control .Sunch as wired -drawing ect .the speed of motor is determined by the load .the speed of ACC/DEC has nothing to do with the ACC/DEC time .

3: PG Vector Control

The inverter have speed sensor vector control (VC). Suitable for high-performance adjusting the speed occasion with installing encoder PG , one inverter can only drive one motor.



TIP

- When F0.01=0 is selected . the motor parameters have to be auto-tuning before first running . In order to get the correct motor parameters . Please make sure the lable of the motor match with the motor parameters of the inverter .Otherwise it will result-in auto-tuning couldn't accomplish or get the wrong results . When it couldn't get the parameters/lable of the motor.It is suggested the user use V/F control.
- When F0.0=1 is selected . Should set the related parameters (F3 Group). To assure the excellent steady dynamic performance.
- Inverter can drive only one motor when F0.00 is set to 0. and the inverter and the capacity class of the motor couldn't be big . Otherwise it will result in the control performance reduce or couldn't work normally .

F0.01 Run command channel

Setting Range:0~2

Factory setting: 0

This function is used to set the inverter receive the control mode which forward, reverse, jog and stop ect control command.

0: Keyboard command channel

To control the inverter start and stop by the key **RUN、STOP、REV/JOG** On the keypad.

1: Terminal command channel

To control the inverter start and stop by external control terminal **Min—COM** on and off .

2: Communication command channel

To control the inverter start and stop by RS485 serial port.

F0.02 Keyboard and terminal UP/Down setting

Setting range:0~3

Factory setting : 0

The frequency can be set by **▲/▼** or encoder on the keypad and terminal UP/DOWN.This setting method have the highest and it can be combined with setting channel .It is used to adjust the output frequency during the commission of the control system .

0: Valid , save the parameters when the inverter is power off .

The frequency command can be set and the value can be saved after the inverter is powered off and it will combinate with the current frequency when it is repowered on .

1: Valid ,the value can not be saved when the inverter is powered off.

The frequency command can be set but the value can not be saved after the inverter is powered off .

2: UP/DOWN setting is valid .

3: valid during running ,the frequency setting value will be clear automatically when the inverter stops .



- When the factory setting is restored ,the value of keypad and UP/DOWN will be cleared .

F0.03 Frequency command selection

Setting range :0~12

Factory setting : 0

This function is used to select the frequency command channel of inverter .

0: Keypad or encoder setting

Modify the value of F0.07 to set the running frequency by the keypad.

And can change the running frequency by the key or encoder on the keypad and terminal UP/DOWN when the inverter is running . The revised frequency value can saved to F0.07 after power off . If you want the frequency can not saved. Upi am set the parameter F0.02.

1 : AI analog setting

The running frequency can be set by the external voltage input terminal AI. Please refer to F5.11~F5.15 .

2 : Reserved

3 : Reserved

4: Potentiometer

This parameter is valid when the keypad with potentiometer.

5: PID control setting

The inverter mode is PID control when this parameter is selected .It's necessary to set F9 group "PID control group". The inverter running frequency is the frequency value after PIF control . and PID given source, Feedback source and so on, Please refer to F9 Group "PID function" introduction .

6: Remote communication setting

The running frequency is set by RS485 communication port .

7~11:Reserved

12.Common PID control setting

F0.04 Maximum output frequency .

Setting Range:10.00~600.00Hz

Factory Setting:50.00 Hz

Set the maximum output frequency of inverter .It's the foundation of frequency settings .and also the basis of speed acceleration and deceleration .Please pay attention to it.

F0.05 Upper limit frequency

Setting range:F0.06~F0.04

Factory Setting :50.00Hz

F0.06 Lower limit frequency

Setting range:0.00~F0.05

Factory Setting:0.00Hz

The upper frequency limit is the inverter allowable working the maximum output frequency . The value should not exceed the the maximum output frequency.

The lower frequency limit is the inverter allowable working the minimum output frequency . The lower limiting frequency is working when the setting frequency is lower than the lower frequency limit .

The value should not exceed the the maximum output frequency.

the maximum output frequency $\geq$ the upper frequency limit $\geq$ the lower frequency limit .

F0.07 keypad setting frequency

Setting range:0.00Hz~F0.04

Factory setting :50.00Hz

When the frequency setting mode F0.03=0 is selected . the parameter is the initial value of inverter setting frequency .

F0.08 Acceleration time 1	Factory setting: Depend on the model
Setting range:0.1~3600.0s	
F0.09 Deceleration time 1	Factory setting: Depend on the model
Setting range:0.1~3600.0s	

The acceleration time is the time of accelerating from 0Hz to Maximum frequency.

The deceleration time is the time of decelerating from maximum frequency to 0Hz. Please refer to the Figure6-1.




Figure 5-1 Acceleration and deceleration time

F0.10 Running direction selection	Factory setting: 0
Setting range:0~2	

To change the running direction of the motor.

0: Forward(the default running direction)

1: Reverse

2: Forbid reverse

F0.11 Carrier frequency

Setting range: 1.0~15.0kHz

Factory setting: Depend on the model

This function is used to set the carrier frequency of the inverter output PWM wave. should adjust correctly . the maximum value of the carrier frequency depend on power. the value of carrier frequency and electromagnetic noise,leakage current and heat dissipation as shown in Figure6-2.

Carrier frequency	electromagnetic noise	leakage current	heat dissipation	Interference
1.0KHz	Big	Small	Small	Small
↕	↕	↕	↕	↕
15.0 KHz	Small	Big	Big	Big
220V Series	380V Series		Setting Range of Carrier Frequency	
0.4-3.7kW	0.75-7.5kW		1.0-15.0kHz	

Figure 5-2 Carrier frequency



- The advantage of high carrier frequency : ideal current waveform ,little current harmonic wave and motor noise .
- The disadvantage of high carrier frequency L increasing the switch loss .increasing the inverter temperature and the impact to the output capacity .the inverter needs to derate on high carrier frequency .at the time ,the leakage and electrical magnetic interference will increase .
- Applying low carrier frequency is contrary to the above. too low carrier frequency will cause unstable running , torque decreasing and surge.

F0.12 Motor parameters autotuning

Setting range:0~2

Factory setting: 0

1: Rotation autotuning

Do not connect any load to the motor when performing autotuning and ensure the motor is in static state. Input the nameplate parameters of motor (F0.01~F0.05) correctly before performing autotuning . Otherwise the parameter detected by autotuning will be incorrect .

Set the proper acceleration and deceleration time (F0.08、 F0.09) according to the motor inertia before performing autotuning . Otherwise it may cause over-current and over-voltage fault during autotuning .

Set F0.12 to 1 then press **ENTER** to start the autotuning . the LED will display and flicker .Press **RUN** to start the autotuning . LED will display **TUN0**. And the motor begin to run after displaying **TUN1**.When the parameter autotuning is finished and will display " **END** ".Finally return to the stop state . when " **TUN** " is flicker,you can press **MODE** to exit out the autotuning status .

You can press STOP/RESET to stop the parameter autotuning operation during autotuning .

2: Static autotuning

If it is difficult to disconnect the load ,static autotuning is recommended . enter the correct motor nameplate parameters of motor (F2.01~F2.05) correctly before performing autotuning.the resistance of stator and rotor and leakage inductance of motor will be tested after autotunign . But mutual inductance and current without load will not be able to measure .users can input the corresponding value according to your experience .



This parameters is valid when vector control F0.00=0 and the keypad control running mode F0.01=0.are selected

F0.13 Restore parameters

Setting range: 0~5

Factory setting: 0

0: No action

1: Restore the default value

Restore all parameters F0~Fd to factory setting except F2 group.

2: Clear fault records

Inverter clear all fault records.

3:Restore the default value to 380V/60Hz.

4:Restore the default value to 440V/50Hz.

5:Restore the default value to 440V/60Hz.

F0.14 AVR Fcuntion

Setting range: 0~2

Factory setting : 0

0: Disable**1: Enable all the time****2: Disabled during deceleration**

AVR(Auto voltage regulation) function is to adjust PWM to stable the output of inverter when the input voltage and rated input voltage have deviation .

This function is disable when the output command voltage is bigger than input power voltage . If AVR is function is disable ,the deceleration time will be short but the current will be big . if AVR is enable all the time .the motor working stable .the deceleration time will be long but the current will be small .

F0.15~F0.16

Reserved

F0.17 Parameter locked

Setting Range :0~1

Factory Setting : 0

The parameter is used to modify permission for setting paramters . Specific set as follows:

0: All parameters are allowed to be rewritten, but some parameters can not be modified when the inverter is running .

1: In addition to the digital frequency setting and this parameter,other parameters prohibited rewritten.

F0.18 Acceleration and deceleration mode selection

Setting Range :0~1

Factory Setting: 0

0: Linear Accel/Decel.

The Output frequency increase or decreases with a constant rate .

1: S-Curve Accel/Decel

To reduce the noise and vibration of the mechanical system, It can slowly change the output frequency at the initial and ending segments of Accel/Decel. as shown in Figure 5-3.




Figure 5-3 Accel/Decel Curve.

F0.19 Temperature alarm switch
Setting Range :0-1

Factory Setting :0

0: Invalid 1:Valid

F0.20 Alarm temperature value
Setting Range:0-85℃

Factory Setting:80

S curve initial segment as shown in Fig.5-3. The slope of the output frequency increases process

S curve end segment as shown in Fig.5-3. The slope of the output frequency decrease process.

A combination of the above parameters, especially for transmission, handling and other load start and stop the process.

F1 Group- Start and stop control

F1.00 Start Mode
Setting range: 0~2

Factory setting: 0

0: Start directly

Start the motor at the starting frequency determined by F1.01.

1: DC braking and start

DC braking at first (Refer to the parameters F1.03 and F1.04).then start the motor at the starting frequency .It is suitable for the motor which have small inertia load and may reverse rotation when start .

2: Speed tracking starting

Can track the rotation and direction of the the motor . Then starting at the tracking speed . running to the setting frequency by acceleration and deceleration time .

F1.01 Direct starting frequency
Setting range:0.00~50.00Hz

Factory setting:1.50Hz

F1.02 Starting frequency maintain time
Setting range:0.0~50.0s

Factory setting:0.0s

The inverter will start at the starting frequency ,As shown in Figure 5-4.In order to ensure enough starting torque .you should set the reasonable starting frequency .

The starting frequency maintain time indicate the starting frequency maintain time when the inverter start . As show in Figure 5-4.




Figure 5-4 Start and stop frequency output curve

F1.03 DC braking current before start.
Setting range:0.0~150.0%
Factory setting:0.0 %
F1.04 DC braking time before start
Setting range:0.0~50.0s
Factory setting:0.0s

DC braking current before start: The inverter start at DC starting . the braking current percentage .

DC braking time before start: the output DC braking current duration time during the inverter starts . this function is invalid when the DC braking time is 0.0s.



TIP

- DC braking current and braking time should be consider the load . the current couldn't be too high .Otherwise the current will trip .It's no suitable to use the DC braking mode and F1.00=1 is valid.

F1.05 Stop mode

Setting range :0~2

Factory setting: 0

0: Ramp to stop

When the stop command takes affect. The inverter decreases the output frequency according to the selected acceleration/deceleration time till stop.

1: Coast/Free stop

When the stop command takes affect, the inverter blocks the output immediately. the motor coasts to stop by its mechanical inertia

2: Deceleration stop + Free stop.**F1.06 Starting frequency of DC braking at stopping**

Setting range:0.00~F0.04

Factory setting:0.00Hz

F1.07 Braking wait time at stopping

Setting range: 0.0~50.0s

Factory setting:0.0s

F1.08 DC braking current at stopping

Setting range: 0.0~150.0%

Factory setting:0.0%

F1.09 DC braking time at stopping

Setting range: 0.0~50.0s

Factory setting:0.0s

F1.06 The frequency of DC braking starting when the inverter is decelerating to stop .

F1.07 The inverter close output for an interval and then braking before DC braking .

F1.08 The percentage of rated current of inverter. The bigger the DC braking current .the greater the braking torque .

F1.09 The maintain time for DC braking at stopping .



- The current of DC braking at stopping set too high .The inverter is easy to trip . Please set the current from small to bigger .
- There is no DC braking when the DC braking time at stopping set to 0.0S.

F1.10 Dead time of FWD/REV

Setting range:0.0~3600.0s

Factory setting:0.0s

Set the interval time at 0.0Hz in the transition between forward and reverse .It is shown as following Figure 5-5.




Figure 5-5 FWD/REV dead time

F1.11 Terminal running protection selection when poweron

Setting range:0~1

Factory setting: 0

In the terminal command mode , when the inverter powered on. The system will automatically detect the status of terminal .

0: Command invalid when powered on .

Although detected effective command of terminal in process of powered on . the inverter will not run .the system is running is the protection state until withdrawal of the terminal operation command .and then enable the terminal.inverter will run .

1: Command valid when powered on

That is to say when the inverter is in the process of powered on . If detected the effective operation the command of terminal . waiting for the completion of initialization. the system will automatically start the inverter .



- The user select this function with caruton .
Otherwise may lead to serious consequences .

F1.12 Input/Output terminal selection

Setting range:0x000~0x7FF

Factory setting :0x000

This function code defines the positive and negative logic of terminals.

Positive logic 0: Valid when connecting SI with corresponding common terminal and invalid when dis connecting these terminal .

Negative logic 1: Invalid when connecting SI with corresponding common terminal and valid when disconnecting these terminals.

If you request X1~X4 is positive logic, X5 is negative logic ,,RY is negative logic .
The setting are as follows :

The logic state of X4~X1 is 0000,and the corresponding hex is 0. The unit digit of LED is displayed to 0. the logic state of X5 is 0001. and the corresponding hex is F. the logic state of RY is 100. and the corresponding hex is 4. The tens digit of LED is The function code of F1.12 is 4F0.As shown in Figure 5-6.

Hundred's place			Decade Place				Unit's place			
0	X	X	X	X	X	0	0	0	0	
RY Y2 Y1			MI8 MI7 MI6 MI5				MI4 MI3 MI2 MI1			
Reserved										

Figure 5-6 Terminal section setting diagram

F1.13 Power off Restart Mode Selection

Setting range:0-2

Factory setting : 0

F1.14 Power Cut Restart Wait Time

Setting range: 0.0-20.0S

Factory setting : 0.5S

F2 Group- Motor parameters**F2.00 Inverter Type**

Setting range:0

Factory setting: 0

0: G Type

Applicable to constant torque load



- The users can set this group parameters to change the inverter type . To realize G/P integration function. It only has G model for 220V inverter .

F2.01 Motor rated power

Setting range:0.4~700.kW

Factory setting: depend on model

F2.02 Motor rated frequency Setting range:0.01~600.00Hz	Factory setting:50.00Hz
F2.03 Motor rated speed Setting range :0~36000rpm	Factory setting: depend on model
F2.04 Motor rated voltage Setting range:0~460V	Factory setting: depend on model
F2.05 Motor rated current Setting range:0.1~2000.0A	Factory setting: depend on model

In order to achieve superior performance .Please set these parameters according to motor nameplate .and then perform auto-tuning .

The power performance of inverter should match the motor .If the bias is too big. The control performances of inverter will be deteriorated distinctly .



- Reset the motor rated power(F2.01) can initialize F2.06~F2.10 automatically .

F2.06 Motor stator resistance Setting range:0.001~65.535 Ω	Factory setting: depend on model
F2.07 Motor rotor resistance Setting range :0.001~65.535 Ω	Factory setting: depend on model
F2.08 Motor leakage inductance Setting range :0.01~655.35mH	Factory setting: depend on model
F2.09 Motor mutual inductance Setting range :0.01~655.35mH	Factory setting: depend on model

F2.10 Current without load

Setting range :0.01~655.35A

Factory setting: depend on model

The above parameters is the necessary parameters for vector control .

The value of F2.06~F2.10 will be sutomatically updated after auto tuning .

Do not change these parameters arbitrarily .otherwise it may deteriotate the control performance of inverter .

F3 Group-Vector control

F3.00 proportional gain 1 of speed loop Setting range:0~10000	Factory setting:15
F3.01 Integration time 1 of speed loop Setting range:0.01~100.00s	Factory setting:2.00s
F3.02 Low switching point frequency Setting range:0.00~F3.05	Factory setting:5.00Hz
F3.03 proportional gain 2 of speed loop Setting range:0~10000	Factory setting:10
F3.04 Integration time 2 of speed loop Setting range:0.01~100.00s	Factory setting:3.00s
F3.05 High switching point frequency Setting range:F3.02~F0.04	Factory setting:15.00Hz

The above parameter are only valid for vector control mode . invalid in V/F control mode .If the frequency is leass than low swithching point frequency (F3.02). we can adopt PI parameter F3.00 and F3.01.If the frequency is more than high switching point frequency 2(F3.05).we can adopt PI parameter F3.00 and F3.04. The PI parameters will be get from the linear change of the two group parameters. As shown in Figure 5-7.

By setting the ratio the speed regulator factors and integration time .you can adjust the speed of dynamic response characteristics of vector control .Increase the proportional gain .reducing the integtation time can speed up the daynamics of the corresponding ring .But the proportional gain is too large or too small intergtation time are easily lead to system oscillation .overshoot is too large . Proportional gain is too small can easily cause the system to steady-state oscillation . and the speed of static difference may exist .

PI speed loop parameters and the inertia motor system are closely related .




Figure 5-7 PI parameter diagram

F3.06 Slip compensation rate of VC

Setting range:50~200%

Factory setting:100%

The parameter is used to adjust the slip frequency of vector control and improve the accuracy of speed control .Properly adjust this parameter can effectively restrain the stativ speed bias .

F3.07 Torque upper-limit setting

Setting range:0.0~200.0%

Factory setting:150%

Set 100% correspondds to the rated output current of the inverter .

F3.08 Torque dynamic friction coefficient	
Setting range:0.000~1.000	Factory setting:0.125
F3.09 Empty load current compensation coefficients	
Setting range:0.000~9.999	Factory setting:0.800
F3.10 Torque static friction coefficient	
Setting range:0.00-10.00	Factory setting:2.00

Torque dynamic friction coefficient is used to adjust the operation of the motor torque value;

Torque static friction coefficient is used to adjust the torque value of the motor not in operation.

F4 V/F Control Group

F4.00 V/F Curve setting	
Setting range::0~6	Factory setting: 0

This group parameter is valid when the inverter in V/F mode($F0.00=1$).

0: Linear Curve .It is applicable for normal constant torque load .

1:Square V/F curve . It is applicable for variable torque load .such as blower , pump and so on .Please refer to following Figure 5-8 .




Figure 5-8 V/F curve

2:User-defined Setting V/F Curve

When selecting this mode ,just set the expected V/F curve through F4.06-F4.11.

As shown in Figure 5-10.

3.1.25 Power V/F Curve

4.1.7 power V/F Curve

5.3 power V/F Curve

6.4 power V/F Curve

Peameters values 3-6 aply to torque-dropped loadsp such as fans and water pumps.See Figure 5-9




Figure 5-9 V/F curve

F4.01 Torque Boost

Setting range: 0.0~30.0%

Factory setting: 2%

F4.02 Torque boost cutoff

Setting range : 0.0~50.0%

Factory setting : 20%

Torque boost will take effect when output frequency is less than cut-off frequency of torque boost (F4.02). The boosting V/F curve as shown in 6-9(1). Torque boost can improve the torque performance of V/F control at low speed. When the torque boost setting is 0.0%, the inverter will boost the output torque according to the load automatically.

Torque boost cutoff: The torque boost is effective below this frequency point, and the torque boost is invalid higher than this frequency point.




Figure 5-9(1) Manual torque boost diagram



CAUTION

- If the torque boost is too high, it will appear the inverter over current protection, and will lead to the motor couldn't start normally. At this time it is reasonable to lower setting value.



- If the torque boost too high . It will appear the inverter over current protection . and will lead to the motor couldn't start normally . At this time It is reasonable tolf the motor working at low frequency for long time . The heat dissipation will become bad .At this time .if the torque boosting value set too high and Intensified this phenomenon. Finally the motor may burnt. Make sure take the motor external forced cooling mode or derating. Keep in mind !

F4.03 V/F Slip compensation limit

Setting range : 0.0~100.0%

Factory setting : 0.0%

The motor's slip changes with the load torque .which result in variance of motor speed .the inverter's output frequency can be adjusted automatically through slip compensation according to the load torque , Therefore the change of speed due to the load change can be reduced ,the value of compensated slip is dependent on the motor's rated slip which can be calculated as $F4.03 = (f_b - n \cdot p / 60) / f_b$.

Where f_b is motor rated frequency (F2.02), n is motor rated speed (F2.03) and P is poles pairs of motor .

F4.04 Auto energy saving selection

Setting range: 0~1

Factory setting : 0

When F4.04 is set to be 1. Where there is light load .It will reduce the inverter output voltage and saves energy .

0: Disable

1: Enabled



- This function is applicable for fan and pump and other load.
- Auto energy saving running is invalid during acceleration and deceleration running.

F4.05 Reserved

F4.06 V/F Frequency Value F1

Setting range: 0.00~F4.08

Factory setting: 12.50Hz

F4.07 V/F Voltage Value V1

Setting range: 0.00~F4.09

Factory setting: 25.00%

F4.08 V/F Frequency Value F2

Setting range: F4.06~F4.10

Factory setting: 25.00Hz

F4.09 V/F Voltage Value V2

Setting range: F4.07~F4.11

Factory setting: 50%

F4.10 V/F Frequency Value F3

Setting range: F4.08~F0.05

Factory setting: 37.50Hz

F4.11 V/F Voltage Value V3

Setting range: F4.09~100.00%

Factory setting: 75.00%

The parameters are used to set the user needs flexible V / F curve. As shown in

Figure 5-10




Figure 5-10 V/F User-defined Curve Setting

F4.12 Low voltage protection selection

Setting range :0-1

Factory setting:0

0: Enabled**1: Disable****F5 Group-Input terminals**

F5.00 MI1 input terminal selection Setting range:0~34	Factory setting: 1
F5.01 MI2 input terminal selection Setting range:0~34	Factory setting: 2
F5.02 MI3 input terminal selection Setting range:0~34	Factory setting: 7
F5.03 MI4 input terminal selection Setting range:0~34	Factory setting: 0
F5.04 MI5 input terminal selection Setting range:0~34	Factory setting: 0
F5.05~F5.07 Reserved	

External input terminal MI1~MI5 are Multi-function input terminal . you can select the function MI1~MI5 by setting the value F5.00-F5.04. The specific setting value and description are as follows

0: No function

1: Forward running

2: Reverse running

The inverter running command is given by the above terminal when the running command channel is terminal control .

3: 3-Wire control

Please refer to the description of P5.09.

4: Jog forward control

5: Jog reverse control

Frequency acceleration and deceleration of jog running .Please refer to description of F8.02~8.04.

6: Coast to stop

The inverter blocks the output immediately .the motor coasts to stop by its mechanical inertia .

7: Reset fault

Fault resets through terminal when the inverter is fault alarming . the function is same to the **STOP** key on your keyboard .

8: External fault input

When an external fault signal sent to the inverter ,the inverter alarm external fault(EF) and stop .

9: Frequency up command

10: Frequency DOWN command

11: Clear frequency UP/DOWN

The above three function to use the external terminal to modify the given frequency . UP is the increment command .DOWN is the decrement command .

Frequency UP/DOWN clearance is to clear the setting value through UP/DOWN .the given frequency to return to a given frequency by the frequency command channel.

12: Multi-step speed terminal 1

13: Multi-step speed terminal 2

14: Multi-step speed terminal 3

15: Multi-step speed terminal 4

16 steps speed control can be realized by the combination of these four terminal . The external terminals of the implementation of speed control must comply with the running command can run. The speed of the terminal control the step speed .as shown in Table 5-1.

Table 5-1 Multi-step speed selection

Multi-step speed terminal 4	Multi-step speed terminal 3	Multi-step speed terminal 2	Multi-step speed terminal1	Multi-step speed selection
OFF	OFF	OFF	OFF	1st step of multi-step speed.The running frequency set by FA.01.
OFF	OFF	OFF	ON	2nd step of multi-step speed.The running frequency set by FA.02.
OFF	OFF	ON	OFF	3rd step of multi-step speed.The running frequency set by FA.03.

Table 5-1 Multi-step speed selection

Multi-step speed terminal 4	Multi-step speed terminal 3	Multi-step speed terminal 2	Multi-step speed terminal 1	Multi-step speed selection
OFF	OFF	ON	ON	4th step of multi-step speed. The running frequency set by FA.04.
OFF	ON	OFF	OFF	5th step of multi-step speed. The running frequency set by FA.05.
OFF	ON	OFF	ON	6th step of multi-step speed. The running frequency set by FA.06.
OFF	ON	ON	OFF	7th step of multi-step speed. The running frequency set by FA.07.
OFF	ON	ON	ON	8th step of multi-step speed. The running frequency set by FA.08.
ON	OFF	OFF	OFF	9th step of multi-step speed. The running frequency set by FA.09.

Table 5-1 Multi-step speed selection

Multi-step speed terminal 4	Multi-step speed terminal 3	Multi-step speed terminal 2	Multi-step speed terminal 1	Multi-step speed selection
ON	OFF	OFF	ON	10th step of multi-step speed. The running frequency set by FA.10.
ON	OFF	ON	OFF	11th step of multi-step speed. The running frequency set by FA.11.
ON	OFF	ON	ON	12th step of multi-step speed. The running frequency set by FA.12.
ON	ON	OFF	OFF	13th step of multi-step speed. The running frequency set by FA.13.
ON	ON	OFF	ON	14th step of multi-step speed. The running frequency set by FA.14.
ON	ON	ON	OFF	15th step of multi-step speed. The running frequency set by FA.15.

Table 5-1 Multi-step speed selection

Multi-step speed terminal 4	Multi-step speed terminal 3	Multi-step speed terminal 2	Multi-step speed terminal 1	Multi-step speed selection
ON	ON	ON	ON	16 th step of multi-step speed.The running frequency set by FA.16.

Note: ON stand for COM port connection . OFF stand for COM port disconnect .

16: Acceleration and deceleration time selection

Select two kinds of acc.and dec. time through the combinations of the number of this two terminals.

Table 5-2 Acceleration and deceleration time selection

Accel.and decal. time selection	Acceleration and deceleration time
OFF	Acceleration and deceleration time 1
ON	Acceleration and deceleration time 2

17: PID control pause

The inverter will keep the current frequency output unchanged when PID is invalid .

18: Traverse frequency pause

Inverter keeps output frequency unchanged .If this terminal is disable. Inverter will continue traverse frequency operation from the current frequency.

19: Traverse frequency reset

The setting frequency of the inverter will return to the centre frequency .

20: Acceleration and deceleration prohibition

Ensure the inverter keep away from the external signal (except the stopping command) and maintain the current output frequency .

21: Disable torque control

The inverter will work shifting from torque control to speed control mode .

22: Clear frequency acc.and dec. settings

When the terminal closed. The frequency set by UP/DOWN can be cleared. Frequency returns to the frequency given by command channel . After the terminal disconnect the frequency returns to the value which is set by UP/Down settings.

23: DC braking when stopping

During the process of decelerating to stop .when this terminal is on ,the inverter will be in the state of DC braking promptly .Braking state is determined by F1.07~F1.09.

24: Reserved**25: Reserved****26: Frequency switch to AI**

The frequency command forced to switch to AI when the terminal closed .and will restore the previous given mode when the terminal disconnected .

27: Reserved**28: Coast to stop control**

The parameter is used to coast to stop for external terminal control mode . the inverter will coast to stop when the terminal closed .

29: Command switch to terminal

The running command channel forced switched to terminal running command channel when the terminal is valid . it will restore previous running command channel after the terminal disconnected .

30: PLC reset

When selecting PLC function . whether automatically input or terminal manual input .Closing the terminal will clear the internal memory of PLC status information . Disconnect the terminal .PLC restart .

31: PLC input

When PLC input model is terminal valid . the terminal is valid and PLC running valid .

32: Count input

For receiving an external pulse signal as the count value.

33: Frequency switch to the combination

The terminal is valid, the frequency given channel forced to switch to combination channel, then restore the original frequency given channel after disconnecting the terminal.

34: Count clear

When set this function , this terminal and COM terminal switch on, the counter value becomes zero.

F5.08 ON/OFF filter time

Setting range: 1~100

Factory setting:5

This parameters is used to set filter strength of terminals(MI1~MI5). When the interference is heavy .the user should increase this value to prevent malfunction .

F5.09 Terminal control running mode

Setting Range:0~3

Factory Setting :0.

This parameter defines four different control modes that control the inverter operation through external terminal .

0: 2-wire control mode 1**1: 2-wire control mode 2**

MI1 setting : Forward running MI2:Reverse running

As shown in table 6-3 and table 6-11

Table 5-3 2-wire controlmode running command

Switch state		2-wire control mode 1	2-wire control mode 2
K2	K1	Running command 1	Running command 2
OFF	OFF	STOP	STOP
ON	OFF	REVERSE	STOP
OFF	ON	FORWARD	FORWARD
ON	ON	STOP	REVERSE

Note: connection is ON .disconnect is OFF.




Figure 5-11 2-wire control diagram

2: 3-wire control mode 1




Figure 5-12 3-wire control mode diagram

3: 3-wire control mode 2

3-Wire control shown in 6-10. MI1 set the Forward running .MI2 is reverse running . MI3 is 3-wire running control terminal .

3-wire control mode 1

K1----- running switch

K2----- Forward and Reverse shifting

K3-----Stop

3-wire control mode 2

K1----- Forward

K2----- Reverse

K3----- Stop

F5.10 UP/DOWN terminal change speed rate

Setting range:0.01~50.00Hz/s

Factory setting:0.50Hz/s

Terminal UP/DWON regulates the incremental rate of setting frequency .

F5.11 AI lower limit

Setting range:0.00~10.00V

Factory setting:0.00V

F5.12 AI lower limit corresponding setting

Setting range:-100.0~100.0%

Factory setting:0.0%

F5.13 AI upper limit

Setting range:0.00~10.00V

Factory setting:10.00V

F5.14 AI upper limit corresponding setting	
Setting range:-100.0~100.0%	Factory setting:100.0%
F5.15 AI input filter time	
Setting range:0.00~10.00s	Factory setting: 0.10s
F5.16~F5.25	
Reserved	

For different applications , the corresponding value of 100.0% analog setting is different . For details. Please refer to description of each application .as shown in Figure 5-13.




Figure 5-13 Analog given and setting

F5.26 Center voltage hysteresis loop width

Setting Range:0.00~10.00V

Factory Setting:0.15V

The paramter is used to adjust the center voltage hysteresis value when F0.03 =8. and will not make calculations withine this range .

F5.27 Cooling Fan control

Setting Range:0~1

Factory Setting :0

0:Auto operation : The fan will run when the inverter starts . and will stop when the inverter stops.

1:The cooling fan is running when the inverter energized on .

F6 Group-Output terminals

F6.00~F6.01 Reserved	
F6.02 Relay output selection Setting range:0~16	Factory setting: 3

This group parameters defines the content represented by the open collector output terminals relay.

0: No output

1: Forward running : Inverter runs forward.has output frequency .Output ON signal at this time .

2: Reverse tuning : Inverter runs reverse.has output frequency .Output ON signal at this time .

3: Fault output : ON: inverter is in fault state .

4: Frequency level detection FDT arrival: Please refer to functional code F8.13.F8.14 for detailed description.

5: frequency reached Please refer to description of P8.15.

6: Zero speed running ON: The running frequency of inverter is Zero.

7: Upper limit frequency reached ON: Running frequency reaches the value of upper limit frequency.

8: Lower frequency limit reached ON: Running frequency reaches to the value of lower limit frequency .

9:Running

When the inverter is running .ON signal will be output .

10: PLC stage completed

Upon the completion of current step of simple PLC running .ON signal with the width of 200ms will be output .

11:PLC cycle completed

Upon the completion of a cycle of simple PLC running .ON signal with the width of 200ms will be output .

12: Overload Pre-alarm

When the inverter output current exceeds overload warning level, An low level active signal will be output after setting the alarm delay time .

13: Specified count value reached

Refer to the fuction of F6.19.F6.20.

14: Setting count value reached

Refer to the fuction of F6.19.F6.20.

15: Reserved**16: Under load output**

F6.03 ~F6.16

Reserved

F6.17 Relay delay closing time

Setting Range:0.1 ~ 3600.0s

Factory Setting: 0.0s

F6.18 Relay delay disconnect time

Setting Range:0.1 ~ 3600.0s

Factory Setting: 0.0s

The parameter is used to control the output relay closing and disconnect delay time.

F6.19 ~F6.22

Reserved

F7 Group-Human-machine interface

F7.00 The user password

Setting range: 0~65535

Factory setting :0

The password protection function will be valid when set to be any nonzero data .

When F7.00 is set to be 0000, the user's password set before will be cleared and the password protection function will be disabled .

After the password has been set and becomes valid .the user can not access menu if the user's password is not correct .Only when a correct the user's password is input, the user can see and modify the parameters .Please keep the user's password in mind .

The password will be valid in 1 minute after retreat the function code edition state . Press MODE to enter into the function code edition state after the password takes effect . 0.0.0.0." will be displayed .the operator should input correct password .

F7.01 The initial selection when Power on

Setting Range :0x0000~0x0C1F

Factory Setting :0x0000

The function code determines the displayed content when the inverter is power on ,The units of LED, decade bits are used to set the running status display selection; hundreds and thousands of LED are used to set the stop status display selection. The initial content display can only select a project, data format is hexadecimal.

Specific display content corresponding to parameter value refer to F7.06-F7.08. For example: The running state and stop state will display the initial count value and input AC voltage . the setting is 0x0A10 .the count value is 16th bit .so hexadecimal is 10. the input ac voltage is the 10 bit .so the hex is 0A.

F7.02 Parameter copy

Setting range : 0~4

Factory setting : 0

The parameter determines the method of parameter copy .

0: No operation

1: All parameters will be uploaded to keyboard . the functions parameters are copied to the keyboard.

2: All parameters will be download to the machine . the parameters of the keyboard are copied to the machine.(Except F2 group.)

3: Reverse

4: The keyboard function parameters are download to the machine . the parameters of the keyboard are copied to the machine .(all).

F7.03 REV/JOG function selection

Setting range : 0~4

Factory setting : 0

This function is used to set the **REV/JOG** keys on the operation panel.

0: Jog operation**1: FWD/REV switching****2: Clear UP/DOWN setting****3:Reverse Running**

4: Fast query : is used to query for the modification parameters.

F7.04 STOP/RESET key stop function selection

Setting range: 0~3

Factory setting : 0

The function code defines the **STOP/RESET** stop function selection .

0: Valid when keypad control

1: Valid when keypad or terminal control

2: Valid when keypad or communication control

3: Always valid

The reset function of **STOP/RESET** Is always valid .

F7.05 Gauge Range Decimal Place	Factory setting: 2
Setting range: 0~3	
F7.06 Running state display parameter selection 1	Factory setting :0x00FF
Setting range :0~0xFFFF	
F7.07 Running state display parameter selection 2	Factory setting :0x0
Setting Range :0~0x3	

The parameters will display the function code when the inverter is running .

which is a 16-bit binary number, if Bit is 1, the corresponding parameters can be running through the SHIFT / "key to view. If Bit is 0 .then the corresponding parameters will not be displayed. Set the function code F7.06 .change a binary number to a hexadecimal number, enter the function code. the content are as follows :

Table 5-5 The display content corresponding to running

F7.06	BIT15	BIT14	BIT13	BIT12	BIT11	BIT10	BIT9	BIT8	F7.07	BIT5	BIT4	BIT3
	Torque setting value	The current step of multi-step	Reserved	Analog AI Value	The output terminal state	The input terminal state	PID feedback value	PID setting value		Reserved	PLC current running remaining time	PLC Current speed
	BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0		BIT2	BIT1	BIT0
	Output torque	Output power	Running torque	Output current	Output voltage	DC bus voltage	Setting frequency	Running frequency		PLC average speed	Output torque	Reserved

F7.08 Stop state display parameter selection

Setting range :0~0x7FF

Factory setting:0x40F

The setting of this function code is the same as that of F7.06. when the inverters are in the stopping state . the displaying of the parameter is determined by the function code.

Table 5-6 The display content corresponding to stop

BIT15	BIT14	BIT13	BIT12	BIT11	BIT10	BIT9	BIT8
The current running remaining time of PLC	The Current speed of PLC	PLC average speed	Linkage Proportion Coefficient	The Count Value	AC Input Voltage	Torque Setting Value	The Current step of Multi-step
BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
Reserved	Analog AI Value	PID Feedback value	PID Setting Value	Output Terminal State	Input terminal state	DC Bus voltage	Setting Frequency

F7.09 IGBT module temperature Setting range: 0.0~100.0℃	Factory Setting:- - - -
F7.10 Software version Setting range: 0.00~9.99	Factory Setting:- - - -
F7.11 Accumulated running time Setting range: 0~65535	Factory Setting:- - - -
F7.12 Runtime psaaword setting Setting Range: 0~65535	Factory Setting:- - - -
F7.13 Runtime setting Setting Range:0~65535h	Factory Setting:- - - -
F7.14 The previous two fault type Setting range:0~29	Factory Setting:- - - -
F7.15 The previous fault type Setting range:0~29	Factory Setting:- - - -
F7.16 The current fault type Setting range:0~29	Factory Setting:- - - -
F7.17 The current fault running frequency Setting range:0.00~600.00Hz	Factory Setting:- - - -
F7.18 The current fault output current Setting range:0.1~2000.0A	Factory Setting:- - - -
F7.19 The current fault DC bus voltage Setting range:0~1000V	Factory Setting:- - - -
F7.20 The current fault temperature Setting Range: 0.0~100.0℃	Factory Setting:- - - -
F7.21 The current fault input terminal state Setting range:0~0xFFFF	Factory Setting:- - - -
F7.22 The current fault output terminal state Setting range:0~0xFFFF	Factory Setting:- - - -

The state of current fault input terminal is displayed as decimal figures. Display the state of all digital input terminals at the latest fault . The order is :

BIT7~BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
Reserved	M15	M#	MB	M2	M#

Current input terminal is ON and the corresponding bit is 0. The state of the digital input terminal at fault can be known through this value .

The state of current fault output terminal is displayed as decimal figures . Display the state of all digital output terminals at the latest fault . The order is :

BIT2	BIT1~BIT0
RY	Reserved

Current output terminal is ON and the corresponding bit is 1. If current output terminal is OFF and the corresponding bit is 0, the state of the digital input terminal at fault can be known through this value .

F8 Group-Enhanced function

F8.00 Acceleration time 2

Setting range : 0.1~3600.0s

Factory setting: Depends on model

F8.01 Deceleration time 2

Setting range : 0.1~3600.0s

Factory setting: Depends on model

Please refer to the instructions of F0.08 and F0.09 for detailed information .

Acc/Dec time 1 and 2 can be switched through multi-function digital input terminals .

Please refer to F5 Group for details information.

For details , Please refer to description of F0.08 and F0.09.

F8.02 Jog frequency	
Setting range:0.00~F0.04	Factory setting:5.00Hz
F8.03 Jog acceleration time	
Setting range:0.1~3600.0s	Factory setting:Depend on model
F8.04 Jog deceleration time	
Setting range:0.1~3600.0s	Factory setting:Depend on model

The meaning and factory setting of F8.02-f8.04 are shown as Figure 5-16.




Figure 5-16 Jog running frequency and Acc./Dec. time



- Jog running : The starting mode F1.00 set 0 and stop mode F1.05 set to 0 to stop.
- The operation panel, the control terminal and the serial port can be jog control.
- In different kinds of operation conditions .Press the jog key . Jog frequency running is priority to progress .

F8.05 Skip frequency	Factory setting :0.00Hz
Setting range :0.00~F0.04	
F8.06 Skip frequency bandwidth	Factory setting :0.00Hz
Setting range :0.00~F0.04	

The settings of F8.05 -F8.06 is mainly to keep the inverter away from the mechanical resonance with the load, you can set a skip frequency point. When the skip frequency point is set to 0, the skip frequency is invalid.




Figure 5-17 Skip frequency setting



In the process of acceleration, deceleration operation .the drive can not jump the skip frequency .

F8.07 Traverse amplitude	Factory setting :0.0%
Setting range :0.0~100.0%	
F8.08 Jitter frequency	Factory setting:0.0%
Setting range :0.0~50.0%	

F8.09 Rise time of traverse	Factory setting:5.0s
Setting range :0.1~3600.0s	
F8.10 Fall time of traverse	Factory setting:5.0s
Setting range:0.1~3600.0s	

Traverse operation is widely used in textile and chemical fiber industry . The typical application is shown in the following figure .

Traverse function means the output frequency of the inverter wobbles with reference frequency as the centre . The track of the output frequency is shown as Figure 5-18. The traverse bandwidth is set by F8.07. when F8.07 is set to 0. The traverse bandwidth is 0 and has no action .




Figure6-18 Traverse operation diagram

Traverse amplitude: Traverse operation frequency is on the subject of upper , lower frequency constraints.

Traverse amplitude (AW)= center frequency (CF)*F8.07

Jitter frequency = traverse amplitude(AW)*F8.08

Rise time of traverse: Indicates the time rising from the lowest traverse frequency to the highest traverse frequency .

Fall time of traverse: Indicates the time falling from the highest traverse frequency to the lowest traverse frequency.

F8.11 Fault auto reset times	
Setting range :0~9999	Factory setting :0
F8.12 Fault reset interval time	
Setting range:0.1~100.0s	Factory setting:1.0s

Auto reset times: when the inverter selects auto reset times . This parameter is used to set the times of auto reset .But if the inverter reset continuously for more than the set time .the inverter will stop for fault and the user has to deal with the problem by hands.

Reset interval: This parameter selects the interval time from fault occurring to auto reset .

F8.13 FDT Level	
Setting range:0.00Hz~F0.04	Factory setting :50.00Hz
F8.14 FDT lag	
Setting range :0.0~100.0%	Factory setting:5.0%

This group of parameters used to set the frequency detection level , when the output frequency is increased by more than than FDT settings. The output open collector signal (lower level), when the ouput frequency drops to the FDT lift the level . The output is invalid signals (high resistance). Shown in Figure 5-19.




Figure 5-19 DFT level diagram

F8.15 Frequency arrival detecting range

Setting range :0.0~100.0%

Factory setting :0.0%

When the output frequency is within the positive and negative detecting range of the setting frequency. The selected output terminal is valid output signal (low level), As shown in Figure 5-20.




Figure 5-20 Frequency arriving detecting diagram

F8.16 Energy Brake threshold voltage

Setting range :115.0~140.0%

Factory setting :125.0%

The function code is used to set the original bus voltage of the energy braking (380V series is 530V, 220V series is 310V). Adjust the value properly can be brake the load effectively.

F8.17 Coefficient of rotation speed

Setting range :0.1~999.9%

Factory setting :100.0%

This parameter is used to calibrate the bias between actual mechanical speed and rotation speed .the formula is as below:

Actual mechanical speed=120*output frequency *F8.17/Number of poles of motor .

F8.18 Energy braking output starting value

Setting Range :0~100%

Factory setting: 0%

control energy braking output proportional to of starting value .If it set to 50%, The parameter will vary between 50%-100%.

F8.19 Inverter overload pre-alarm selection

Setting Range:00~12

Factory setting: 00

LED bit, overload pre-alarm detection selection

0: No detection

1: Running Detection

2:Constant speed detection

LED ten digit, overload pre-alarm action selection

0: No alarm, continue running

1: OL3 alarm, stop running

LED Hundred digit. under load pre-alarm detection selection

0: No detection

1: Under load when Running Detection

2: Under load when Constant speed detection

LED Thousand digit. under load pre-alarm action selection

0: No Alarm. Continue running

1: UI4 Alarm. stop running.

F8.20 Overload pre-alarm level

Setting Range :0.0~150.0%

Factory setting: 130.0%

F8.21 Overload detection time

Setting Range: 0.0~6500.0s

Factory setting: 5.0s

Overload pre-alarm level defines the current threshold of overload pre-alarm action . the setting range is relative to the percentage of rated current .The general overload pre-alarm level should be set lower than the overload protection level.

When the output current reaches the overload pre-alarm level, and its continued level exceeds to setting's overload pre-alarm action time .overload pre-alarm will be action.shown in Figure 5-21.




Figure 5-21 Overload pre-alarm schematic

F8.22 The decrease rate of droop control frequency

Setting Range : 0.00~15.00%

Factory Setting : 0.00%

the inverter output frequency will vary with load . mainly used to drive the power balance of the same load for multi-motor .

F8.23 ENA Mode and Fan control

Setting Range: 0~11

Factory setting : 00

Units digit: 0: ENA OFF, 1: ENA ON

Decade: 0: Fan start working

1: Fan couldn't working below 0 °C

F8.24 The proportional gain of ENA frequency increases

Setting Range: 0 ~ 100.00

Factory setting : 0.10

The proportional gain of ENA frequency increases . The bigger setting value . The faster change . But it couldn't too fast . The frequency increase too fast . The motor shock badly .

F8.25 ENA Integration time

Setting Range: 0.01~100

Factory setting : 0.10

ENA Integration time. The larger the setting, the smaller the frequency change. The smaller the setting, the faster the frequency changes, but if the frequency increases too fast. Motor shock badly.

F9 Group-PID control

PID control is a common used method in process control such as flow, pressure and temperature control. The principle is firstly detect the bias between preset value and feedback value, then calculate output frequency of inverter according to proportional gain, integral and differential time. Please refer to following Figure 5-22.




Figure 5-22 PID control diagram

F9.00 PID given source selection

Setting range :0~5

Factory setting :0

- 0: Keypad (F9.01)**
- 1: Analog channel AI given**
- 2: Reserved**
- 3: Remote communication given**
- 4: Multi-step speed given**
- 5: keyboard direct given**

When frequency source select PID, F0.03 set to 5. F9 group function will be effect. This parameter determines the goal of the process PID given channel. the setting target of process PID is relative value. 100% preset value is corresponding to 100% of feedback value. the system will operate according to the relative value (0 to 100%).



TIP

Multi-step given can set the parameters of FA group.

F9.01 Keyboard preset PID given

Setting range :0.00~F9.16

Factory setting :0.00M Pa

Select F9.00 = 0, the target source is the keyboard given. This parameter is the reference value as the amount of feedback.

F9.02 PID feedback source selection

Setting range :0~3

Factory setting :0

0: Analog channel AI feedback**1: Reserved****2: Reserved****3: Remote communication feedback**

These parameters are used to select PID feedback channel.



- Preset source and feedback source must not be same. Otherwise given and feedback will be the same. the difference is 0. PID will not work.

F9.03 PID output characteristics selection

Setting range :0~1

Factory setting :0

0: PID output is positive. When the feedback value is greater than the preset value. Output frequency will be decreased. such as tension control in winding application.

1: PID output is negative. when the feedback value is greater than the preset value. Output frequency will be increased. such as tension control in unwinding application.

F9.04 Proportional gain Kp

Setting range :0.00~100.00

Factory setting :1.00

Proportional gain Kp determines the adjusting strength of the PID adjustor. the large the value of P. the stronger the adjusting strength is.

F9.05 Integral time T_i

Setting range:0.01~100.00s

Factory setting:0.10s

The Integral time T_i determines the ratio between the output frequency change speed and deviation. Integral role is the output value will integrate according to the deviation, to eliminate the deviation of feedback value and given value. Integration time is too large, the response is slow, slow response to external disturbances. The integration time is smaller, faster response speed, but too small and easy to cause oscillation.

F9.06 Differential time T_d

Setting range:0.01~100.00s

Factory setting :0.00s

Differential time T_d : when the error between the feedback and the reference. a proportional adjustment will be output. The adjustment only depends on the direction and value of the error change other than the error itself. The derivation adjustment controls the change of feedback signal according to the changing trend when it fluctuates. Because the derivation may enlarge the interference to the system, especially the frequency-changing interference. Please use it carefully.

F9.07 Sample cycle T

Setting range:0.01~100.00s

Factory setting:0.10s

Sample cycle T refers to the sampling cycle of feedback value. The PI regulator calculates once in each sampling cycle. the bigger the sampling cycle. the slower the response is.

F9.08 Bias limit

Setting range:0.0~100.00%

Factory setting:0.0%

Bias limit defines the maximum bias between the feedback and the preset . PID stops operation when the bias is within this range . Setting this parameter correctly is helpful to improve the system output accuracy and stability .




Figure 5-23 Bias limit action diagram

F9.09 Feedback lost detecting value	
Setting range:0.0~100.0%	Factory setting :0.0%
F9.10 Feedback lost detecting time	
Setting range: 0.0~3600.0s	Factory setting: 1.0s

Feedback lost detecting value is relative to 100% .The system will detect the feedback pf PID all the time .when the feedback value is below or equal to the feedback offline detection value .the system will begin to count the detecting time . when the time exceeds the feedback offline detection time .the system will report PIDE.

F9.11 Feedback gain	
Setting range:0~200.0%	Factory setting:100%

When the feedback value is not same as the actual target value . this parameter can be used to adjust the feedback signal .

F9.12 Awakening threshold Width	Factory setting:0.50 MPa
Setting range:0.00~F9.16	
F9.13 Awakening threshold detection time	Factory setting:1.00s
Setting range:0.00~360.00s	
F9.14 Sleep Frequency	Factory setting: .30.00Hz
Setting range: 0.00~F0.04	
F9.15 Sleep Frequency Detection Time	Factory setting:1.00s
Setting range:0.00~360.00s	

F9.12 is the water supply system of the pressure threshold from sleep into the working state . when the pressure of the pipe network is less than the set value,Inverter pass delay waiting of F9.13, the frequency of water supply system automatically transferred to the working state from hibernation.

F9.14 refers to the lowest operating frequency of PID system from working state to sleeping state.

When the feedback value is greater than or equal to the set value, and the inverter PID system has adjusted the output frequency to the sleep frequency operation, the inverter pass delay waiting of F9.15 and enters into a sleep state (zero speed operation) waiting for awake .See Figure 5-24.




Figure 5-24 Sleep and Awake function diagram

F9.16 The gauge range

Setting Range :0.00~20.00MPa

Factory Setting: 20.00MPa

The parameter is used to set the gauge range .

F9.17 PID preset frequency

Setting Range :0.00~F0.05

Factory Setting:0.00Hz

F9.18 Preset frequency maintain time

Setting Range:0.00~360.00s

Factory Setting:0.00s

This parameter is used to set the PID running frequency and time before running.

FA Group –Multi- step speed control**FA.00 PLC Mode**

Setting Range:0000~1111

Factory Setting :0000

LED Unit's Place : PLC running mode selection

0: invalid

1: single circulation

2: continuous circulation

3: single circulation keep the final value .

LED Decade;PLC input selection

0: Automatic control

1: Terminal Control

LED Hundreds place :

PLC breakpoints recovery options

0: Restart from the first stage frequency.

1: Restart from running frequency .which is saved before the sunning is breaking .

2: Restart from setting frequency when running is break.

2: Continuous Cycle

The inverter multi-step running repeatedly cycle, the inverter will stop unless stop command given, shown in Figure 5-26




Figure 5-26 PLC / multi-speed continuous cycle running

3: Keep the final value after a single cycle

The inverter complete a single cycle . set the setting frequency and direction running according to the last running time setting for multi-stage speed is not 0. as shown Fig6-27.




Figure 5-27 PLC / multi-speed keep the final value after a single cycle running

FA.01 Multi-step speed 1 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.02 Multi-step speed 2 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.03 Multi-step speed 3 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.04 Multi-step speed 4 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.05 Multi-step speed 5 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.06 Multi-step speed 6 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.07 Multi-step speed 7 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.08 Multi-step speed 8 Setting range: F0.06-F0.04	Factory setting : 0.00Hz
FA.09 Multi-step speed 9 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.10 Multi-step speed 10 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.11 Multi-step speed 11 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.12 Multi-step speed 12 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.13 Multi-step speed 13 Setting range: F0.06-F0.04	Factory setting: 0.00Hz

FA.14 Multi-step speed 14 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.15 Multi-step speed 15 Setting range: F0.06-F0.04	Factory setting: 0.00Hz
FA.16 Multi-step speed 16 Setting range: F0.06-F0.04	Factory setting: 0.00Hz


FA.17 Unit of PLC Running time Setting range: 0-1 0: second 1: minute	Factory setting: 0
FA.18 Curve selection Setting range: 0-1	Factory setting: 0

0: Mode 1- Linear operation

We often see 16 Multi-step controlling in inverter's

In linear operation every step start with main acceleration /deceleration for reaching it given frequency "F" .


LINEAR OPERATION



2: Mode 2 (No wait time) -Gradual operation

In gradual operation frequency “F” increasing /decreasing with respect to time “T” in all 16 steps .If the step frequency is set to Zero . the step will be ended .

GRADUAL OPERATION



FA.19 Multi-speed direction source selection

Setting Range:0~1

Factory Setting :0

The multi-speed direction is external control when FA.16=0 .

The multi-speed direction decided by itself symbol when FA.16=1.

if FA.16 is negative . The multi-speed direction is reverse direction running .

Frequency set to 100.0% corresponding to the maximum frequency (F0.04).

Multi-speed takes precedence over the keyboard, analog communication frequency input, can select up to 16 steps speed through a combination of coding Xn, specifically refer to the instructions F5 group parameter.

the start and stop channel selection of multi-speed running are also determined by the function code F0.01.

FA.20 PLC Accel/Decel Time 1 Setting Range:0.01~3600.0s	Factory Setting:20.0s
FA.21 PLC Accel/Decel Time 2 Setting Range:0.01~3600.0s	Factory Setting:20.0s
FA.22 PLC Accel/Decel Time 3 Setting Range:0.01~3600.0s	Factory Setting:20.0s
FA.23 PLC Accel/Decel Time 4 Setting Range:0.01~3600.0s	Factory Setting:20.0s
FA.24 PLC Accel/Decel Time 5 Setting Range:0.01~3600.0s	Factory Setting:20.0s
FA.25 PLC Accel/Decel Time 6 Setting Range:0.01~3600.0s	Factory Setting:20.0s
FA.26 PLC Accel/Decel Time 7 Setting Range:0.01~3600.0s	Factory Setting:20.0s
FA.27 PLC Accel/Decel Time 8 Setting Range:0.01~3600.0s	Factory Setting:20.0s

FA.20 - FA.27 is used to set PLC acceleration and deceleration time of multi-speed 1-16.

FA.28 Acceleration Selection 1	Factory Setting : 0x1111
FA.32 Deceleration Selection 1	Factory Setting: 0x1111

Setting Range:

Unit's Place: Multi-Speed 1 FA.20-FA.27.

Decade : Multi-Speed 2 FA.20-FA.27.

Hundreds place: Multi-Speed 3 FA.20-FA.27.

Thousands place: Multi-Speed 4 FA.20-FA.27.

FA.29 Acceleration Selection 2	Factory Setting : 0x1111
FA.33 Deceleration Selection 2	Factory Setting: 0x1111

Setting Range:

Unit's Place : Multi-Speed 5 FA.20-FA.27.

Decade: Multi-Speed 6 FA.20-FA.27.

Hundreds place : Multi-Speed 7 FA.20-FA.27.

Thousands place : Multi-Speed 8 FA.20-FA.27.

FA.30 Acceleration Selection 3	Factory Setting : 0x1111
FA.34 Deceleration Selection 3	Factory Setting: 0x1111

Setting Range:

Unit's Place : Multi-Speed 9 FA.20-FA.27.

Decade: Multi-Speed 10 FA.20-FA.27.

Hundreds place : Multi-Speed 11 FA.20-FA.27.

Thousands place : Multi-Speed 12 FA.20-FA.27.

FA.31 Acceleration Selection 4	Factory Setting : 0x1111
FA.35 Deceleration Selection 4	Factory Setting: 0x1111

Setting Range:

Unit's Place : Multi-Speed 13 FA.20-FA.27.

Decade: Multi-Speed 14 FA.20-FA.27.

Hundreds place : Multi-Speed 15 FA.20-FA.27.

Thousands place : Multi-Speed 16 FA.20-FA.27.

FA.36 Direction Selection 1

Factory Setting: 0x0000

Setting Range:

Unit's Place : Multi-Speed 1 (0-1) 0:Forward 1:Reverse

Decade: Multi-Speed 2 (0-1) 0:Forward 1:Reverse

Hundreds place: Multi-Speed 3 (0-1) 0:Forward 1:Reverse

Thousands place: Multi-Speed 4 (0-1) 0:Forward 1:Reverse

FA.37 Direction Selection 2

Factory Setting: 0x0000

Setting Range:

Unit's Place : Multi-Speed 5 (0-1) 0:Forward 1:Reverse

Decade: Multi-Speed 6 (0-1) 0:Forward 1:Reverse

Hundreds place: Multi-Speed 7 (0-1) 0:Forward 1:Reverse

Thousands place: Multi-Speed 8 (0-1) 0:Forward 1:Reverse

FA.38 Direction Selection 3

Factory Setting: 0x0000

Setting Range:

Unit's Place : Multi-Speed 9 (0-1) 0:Forward 1:Reverse

Decade: Multi-Speed 10 (0-1) 0:Forward 1:Reverse

Hundreds place: Multi-Speed 11 (0-1) 0:Forward 1:Reverse

Thousands place: Multi-Speed 12 (0-1) 0:Forward 1:Reverse

FA.39 Direction Selection 4

Factory Setting: 0x0000

Setting Range

Unit's Place : Multi-Speed 13 (0-1) 0:Forward 1:Reverse

Decade: Multi-Speed 14 (0-1) 0:Forward 1:Reverse

Hundreds place: Multi-Speed 15 (0-1) 0:Forward 1:Reverse

Thousands place: Multi-Speed 16 (0-1) 0:Forward 1:Reverse

FA.40 PLC Running Time 1 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.41 PLC Running Time 2 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.42 PLC Running Time 3 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.43 PLC Running Time 4 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.44 PLC Running Time 5 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.45 PLC Running Time 6 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.46 PLC Running Time 7 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.47 PLC Running Time 8 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.48 PLC Running Time 9 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.49 PLC Running Time 10 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)

FA.50 PLC Running Time 11 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.51 PLC Running Time 12 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.52 PLC Running Time 13 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.53 PLC Running Time 14 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.54 PLC Running Time 15 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)
FA.55 PLC Running Time 16 Setting Range : 0.0-6553.5 S(Min)	Factory Setting : 0.0S(Min)

FA.40- FA.55 is used to set PLC multi-speed running time 1-16.

Fb Group –Protection function

Fb.00 Motor overload protection Setting range :0~2	Factory setting :2
---	--------------------

0: Disable.

without motor overload protection features (caution), at this time the drive don't have overload protection for the load motor.

1: For normal motor . (with low speed compensation) .the lower the speed,the poorer the cooling effect .based on this reason . If output frequency is lower tha 30Hz. The inverter will reduce the motor overload protection threshold to prevent normal motor from overheat .

2: The variable frequency motor (without low speed compensation) . As the cooling effect of variable frequency motor has nothing to do with running speed . it is not required to adjust the motor overload protection threshold.

Fb.01 Motor overload protection current

Setting range:20.0~120.0%

Factory setting:100.0%

If the power rating of the inverter do not match with the motor , you can modify the parameters to achieve the purpose of protecting the motor. as shown in Figure 5-28.

The value cn be determined by the following formula :

Motor overload protection current=(motor rated current/inverter rated current)*100%.




Figure 5-28 Motor overload protection curve

Fb.02 Momentary power drop frequency point

Setting range :70.0~110.0%

Factory setting:80.0%

Fb.03 Momentary power drop frequency rate of decline

Setting range:0.00~F0.04

Factory setting:0.00Hz

If Fb.03 is set to 0. Momentary power drop frequency is invalid .

Momentary power drop frequency point enable the inverter to perform low voltage compensation when DC bus voltage drops below Fb.02. the inverter can continue to run without tripping by reducing its output frequency and feedback energy via motor.



TIP

- Please adjust these two parameters properly .It can avoid in the switch of the power grid . and production stop caused by inverter protection .

Fb.04 Over-voltage stall protection	
Setting range : 0~1	Factory setting:1
Fb.05 Over-voltage stall protection voltage	
Setting range:110~150%	Factory setting:130%

0: Disable .

1: Enable

During deceleration .the motor's decelerating rate may be lower than that of inverter's output frequency due to the load inertia .at this time .the motor will feed the energy back to the inverter .resulting in DC bus voltage rise .If no measure taken .the inverter will trip due to over voltage .

Over-Voltage stall protection iis the inverter detects DC bus voltage .

And compares it with over voltage stall protection point Fb.05. (Relative to the standard bus voltage: 380V Series 530,220 V Series 310V).

If DC bus voltage exceeds Fb.05, the inverter will stop reducing its output frequency . when the DC bus voltage become lower than Fb.05. the deceleration continues , as shown in following Figure 5-29.




Figure 5-29 Over voltage stall function

Fb.06 Auto current limiting threshold
Setting range: 20~200%
Factory Setting: 160%
Fb.07 Frequency decrease rate when current limiting
Setting range: 0.00~100.00Hz/s
Factory Setting: 10.00Hz/s

Auto current limiting is used to limit the current of inverter smaller than the value determined by Fb.06 in real time. Therefore the inverter will not trip due to surge over-current. This function is especially useful for the applications with big load inertia or step change of load.

Fb.06 is a percentage of the inverter's rated current.

Fb.07 defines the decrease rate of output frequency when this function is active. If Fb.06 is too small, overload fault may occur. If it is too big, the frequency will change too sharply, therefore, the feedback energy of motor will be too large and may cause over-voltage fault. This function is always enabled during acceleration and deceleration. Constant speed current limiting is valid or not determined by Fd.09.

Note:

* During auto current limiting process, the inverter's output frequency may change; therefore, it is recommended not to enable the function when requires the inverter's output frequency stable.

* During auto current limiting process, if Fb.06 is too low, the overload capacity will be impacted.

Please refer to following figure.




Figure 5-30 Auto current limiting function

Fb.08 Input phase loss protection selection

Setting Range: 0~2

Factory Setting : Depend on the model

In standay (hardware detectioun valid) or running (Software or hardward detection valid), The inverter will appears LP input phase loss protection due to the power phase shortage and three phase input power imbalance

0: Invalid

1: software detect is valid

2: hardware detect is valid



- The software detection is only valid for the model G030T4/P037T4 and G015T2 and below power. No hardware detection. While there have software and hardware options when the inverter is power bigger than 30kW.

Fb.09 Under load protection current

Setting Range: 0~10000

Factory Setting: 0

Fb.10 Under load protection Time

Setting Range: 0~1

Factory Setting: 5.0

FC Group Serial communication

FC.00 Local address

Setting range: 0~247

Factory setting : 1

This parameter determines the slave address used for communication with master. The value "0" is the broadcast address.

FC.01 Baud rate selection

Setting range: 0~5

Factory Setting: 4

This parameter can set the data transmission rate during serial communication.
Note: The baud rate of master and slave address must be the same.

- 0: 1200BPS**
- 1: 2400BPS**
- 2: 4800BPS**
- 3: 9600BPS**
- 4: 19200BPS**
- 5: 38400BPS**

FC.02 Data bit check setting

Setting Range : 0~17

Factory Setting :1

This parameter defines the baud rate in serial communication, and data format used in protocols , only a consistent format can be normal communication.

- 0:No parity check (N, 8, 1) for RTU**
- 1: Even parity check (E, 8, 1) for RTU**
- 2: Odd parity check (O, 8, 1) for RTU**
- 3: No parity check (N, 8, 2) for RTU**
- 4: Even parity check (E, 8, 2) for RTU**
- 5: Odd parity check (O, 8, 2) for RTU**
- 6: No parity check (N, 7, 1) for ASCII**
- 7: Even parity check (E, 7, 1) for ASCII**
- 8: Odd parity check (O, 7, 1) for ASCII**
- 9: No parity check (N, 7, 2) for ASCII**
- 10: Even parity check (E, 7, 2) for ASCII**
- 11: Odd parity check (O, 7, 2) for ASCII**
- 12: No parity check (N, 8, 1) for ASCII**
- 13: Even parity check (E, 8, 1) for ASCII**
- 14: Odd parity check (O, 8, 1) for ASCII**
- 15: No parity check (N, 8, 2) for ASCII**
- 16: Even parity check (E, 8, 2) for ASCII**
- 17: Odd parity check (O, 8, 2) for ASCII**

The upper computer and the data format of the inverter must be consistent .
Otherwise , Communication can't work .

FC.03 Communication answer delay time

Setting range: 0~200ms

Factory Setting: 5ms

Answer delay: The interval time between the data receiving of the inverter and data sending to the upper monitor. If the answer delay is shorter than the system time, then it is subject to the system time, and if the answer delay is longer than the system, then the waiting time should be prolonged after the data processing to achieve the answer delay and then to send data to the upper monitor.

FC.04 Communication timeout fault time

Setting range: 0.0~200.0s

Factory Setting: 0.0s

If the function code is set to 0.0s, this parameter is invalid.

If the function code is set to a valid value, when the interval time exceeds the communication overtime, the system will report communication fault (CE 1).

Generally, the parameter is set to invalid. If the parameter is set in a continuous communication system, the communication state can be monitored.

If it doesn't receive correct data signal during the delay time of FC.04, the inverter will determine stop or remain the state according to the solution of communication fault.

FC.05 Communication error action

Setting range: 0~3

Factory Setting: 1

0: Alarm and coast to stop

1: Do not alarm and keep running

2: Do not alarm and stop at the stopping method (only for communication control mode)

3: Do not alarm and stop at the stopping method (for all communication control modes)

In the abnormal situation, the inverter can act through setting communication fault processing. The selected running state of the inverter is: shield the CE fault, stop or keep running.

FC.06 Response action

Setting range: 0~1

Factory Setting : 0

0: Response to reading and writing

1: No response to writing

FC.07 Communication parameters address mode

Setting Range:0~1

Factory Setting :0

0: The address is calculated according to the parameter group.

1:The address is calculated in sequence.increased one by one since F0.00.

FC.08 Linkage proportion coefficient

Setting Range:0.01~10.00

Factory Setting:1.00

when the local machine is set by the master inverter control . the setting frequency is given by the main station . the parameter is used to set the local machine as a slave via RS485/RS232 interface receiving the weight coefficient of the frequency command .

The actual setting frequency of the load machine is equal to the value of the parameter is multiplied by RS485 / 232 interface receives the frequency setting command value.

FC.09 Linkage proportion source selection

Setting Range:0~4

Factory Setting:0

0: Keypad or Encoder Setting (FC.08)**1: Annlog AVI setting****2: Annlog ACI setting****3: Multi-stage setting****4: Keyboard or encoder direct setting****Fd Group Supplementary function**

Fd.00 Low-frequency threshold of restraining oscillation

Setting range: 0~500

Factory Setting: 5

Fd.01 High-frequency threshold of restraining oscillation

Setting range: 0~500

Factory Setting: 5

Most motors may have current oscillation at some frequency point. Please be cautious to adjust these parameters to weaken oscillation.

This function is only valid when Fb.04 is set to be 0. The smaller the value of Fd.00 and Fd.01, the stronger the restraining effect.

Fd.02 Amplitude of restraining oscillation

Setting range: 0~100

Factory Setting: 10

This parameter is used to limit the strength of restraining oscillation. If the value of Fd.02 is too big, it may cause inverter over current. It should be set a little bit smaller for large power motor, vice versa.

Fd.03 Threshold high-low frequency of restraining oscillation

Setting range: 0.00~F0.04

Factory Setting : 12.50Hz

If output frequency is greater than Fd.00 takes effect, otherwise Fd.01 takes effect.

Fd.04 Restrain oscillation

Setting range: 0~1

Factory setting: 1

0: Enabled**1: Disabled**

Motor always has current oscillation when its load is light. This will cause abnormal operation even over-current. For details, please refer to description of Fd.00~Fd.03.

Fd.05 PWM mode

Setting range: 0~2

Factory Setting: 0

0: PWM mode 1 with low noise in lower frequency and high noise in higher frequency.

1: PWM mode 2 with low noise. But it is need to be derated, because of higher temperature rise.

2: PWM mode 3 with high noise. But it can more effectively restrain the oscillation.

Fd.06 Torque setting mode selection

Setting range: 0~5

Factory Setting: 0

Fd.07 Keypad torque setting

Setting range: -200.0~200.0%

Factory Setting: 50%

0: Keypad**1: AI****2: Reserved****3: Reserved****4: Multi-step setting****5: Communication**

When torque control takes effect,

If $T_{set} > T_{load}$, output frequency will increase continuously until it reaches upper frequency limit.

If $T_{set} < T_{load}$, output frequency will decrease continuously until it reaches lower frequency limit.

Inverter can run at any frequency between upper and lower frequency limit only when $T_{set} = T_{load}$.

Torque control can be switched to speed control, vice versa.

Switching by multi-functional terminal: For example, if torque control is enabled ($P0.00=2$), torque setting source is AVI, the value of multi-function terminal S5 is set to 20 (Disable torque control). When S5 is valid, control mode will switch from torque control to speed control, vice versa.

When running at torque control mode, press the key: STOP/ RST, it will switch to speed control automatically.

If torque setting is positive, inverter will run forward; otherwise it will run reverse.

Note:

When running at torque control mode, the acceleration time has nothing to do with F0.08.

The 100% of torque setting is corresponding to 100% of F3.07 (Torque limit). For example, if torque setting source is keypad ($Fd.06=0$), $Fd.07=80\%$ and $F3.07=90\%$, then Actual torque setting $=80\% (Fd.07) \times 90\% (F3.07) = 72\%$.

Fd.08 Upper frequency limit selection

Setting range: 0~4

Factory Setting: 0

0: Keypad

1: AI

2: Reserved

3: Multi-step setting

4 : Communication

The 100% of this parameter is corresponding to 100% of F0.04 (maximum frequency). When running at torque control mode, output frequency can be adjusted by changing upper frequency limit.

Fd.09 Auto current limiting selection

Setting range:0~1

Factory Setting:0

0: Enabled when constant speed

1: Disabled when constant speed

This function is always enabled during acceleration or deceleration period.

Auto current limiting function is used to prevent inverter trip over-current from surge current. It is especially useful for the applications with big load inertia or step change of load.

Note: During auto current limiting process, the inverter's output frequency may change; therefore, it is recommended not to enable the function when output frequency need to be stable.

Fd.10 Lower limit frequency running mode

Setting range :0~1

Factory Setting :0

Action mode when running frequency reached to lower limit frequency .

0: lower limit frequency running

1:Zero frequency running and DC braking .

Fd.11 Zero-frequency running braking current

Setting Range:0.0~150.0%

Factory Setting :0.0%

Set value of DC braking current when Zero frequency operation .It's invalid when Fd.11=0%

6. Common Fault & Anomalies and Solutions

6.1 Fault Code and Solutions

Table 6-1 Common problem and solutions

Fault code	Fault Type	Reason	Solution
oCA	Over-current when acceleration	① Acc time is too short. ② The load inertia is too big. ③ The torque increases too fast or V/F curve is abnormal. ④ The voltage of the power supply is too low. ⑤ The power of inverter is too low. ⑥ Restart the rotating motor after sudden power loss.	① Increase Acc time. ② Reduce the load inertia. ③ Lower the load lift or adjust V/F curve. ④ Check the power of supply line. ⑤ Select a bigger capacity inverter. ⑥ Set the start mode F1.00 to rotating tracking start
oCd	Over-current when deceleration	① Dec time is too short. ② The inertia of the load is too strong. ③ The power of the inverter is too low.	① Increase dec time. ② Decrease the inertia of the load. ③ Select a bigger capacity inverter.
oCn	Over-current when constant speed running	① The input power is abnormal. ② The load is transient. ③ The power of the inverter is too low.	① Check the input power ② Decrease the load transients. ③ Select a bigger capacity inverter.
oVA	Over-voltage when acceleration	① The input voltage changes abnormally. ② Restart the rotating motor after sudden power loss.	① Check the input power. ② Set the start mode F1.00 to rotating tracking start
oVd	Over-voltage when deceleration	① Dec time is too short. ② Load with energy feedback ③ The input power is abnormal.	① Properly extend the dec time ② Select the proper energy-consumption braking components ③ Check the input power.
oVn	Over-voltage when constant speed running	① The input power is abnormal. ② Load with energy feedback ③ The voltage detection channel is abnormal	① Check the input power. ② Install or select the proper energy-consumption braking components ③ Ask for service.

Fault code	Fault Type	Reason	Solution
OU5	Over-voltage when stop	①The input power is abnormal.	① Check the input power.
LU	Under voltage when running	①The input voltage is too low. ②Sudden power loss. ③Input power fault. ④Poor contact of the DC circuit. ⑤Contactor with poor contact.	①Check the input voltage ②Reset the inverter and check the input power. ③Whether the power supply voltage waveform is good, whether there is a large inrush current or lack of phase or short circuit ④Check the main circuit or ask for service. ⑤Check the contactor or ask for service.
LP	Input phase loss	① R,S and T phase loss	①Check the input voltage ②Check installation wiring
SPD	Output phase loss	①The three-phase load is severely unsymmetrical	①Check installtion distribution ②Check the output wiring
SC	IGBT Fault	①Inverter output three-phase short circuit or ground fault ②Inverter instantaneous overcurrent, ③The ambient temperature is too high; ④ The air duct is blocked or the fan is damaged; ⑤ DC auxiliary power supply failure; ⑥ The control board is abnormal	①Check the distribution. ②Refer to the overcurrent solution. ③Low the ambient ④Dredge the wind channel or change the fan. ⑤Ask for service ⑥Ask for service
OH1	Radiator overheated	①Ambient temperature is too high. ②fan damage ③Air duct jam	①Reduce the ambient temperature; ②Replace the fan; ③Clean up the air duct and improve ventilation condition;
OL1	Motor overload	①The torque boost is too high or the V/F curve is not suitable; ②The grid voltage is too low; ③The motor is blocked or the load changes suddenly; ④Improper setting of motor overload factor;	①Reduce the torque boost value or adjust the V/F curve; ②Check the grid voltage; ③Check the load and motor status; ④ Set the motor overload protection coefficient Fb.01 correctly;

Fault code	Fault Type	Reason	Solution
OL2	Inverter overload	①The torque increases too fast or V/F curve is abnormal ②Acc. Time is too short. ③The load is too large ④The voltage of the grid is too low	①Lower the value of torque increases or adjust V/F curve ②Increase the Acc. Time ③ Select a large power inverter ④ Check the voltage of the grid
OL3	Inverter pre-overload	①Reached the overload pre-level ②Overload pre-level value setting improper	Set proper overload pre-water Average
EF	External fault	External equipment fault input Child closure	Disconnect the external equipment fault input terminal and clear the fault
I EE	Current detection error	① The Hall device is damaged or the circuit is faulty; ②The DC auxiliary power supply fails	①Ask for service ②Ask for service
EE	Motor self-learning failure	①The motor capacity doesn't comply with the inverter capacity ②Improper setting of motor parameters ③The deviation between the self-learned parameters and the standard parameters is too large ④Self-learning timeout	①Change the inverter mode ②Set the rating parameters according to the nameplate of the motor ③Empty the motor and identify again ④Check the motor wiring and set the parameters
EEP	Read and write failure	①An error occurred in the reading and writing of control parameters ②The EEPROM is damaged	①Ask for service ②Ask for service
PI dE	Feedback disconnection fault	①PID feedback disconnection ②PID feedback source disappears	①Check the PID feedback signal line ②Check the PID feedback source
dCE	The main chip fault	①Damage to the main chip	①Seek service

Fault code	Fault Type	Reason	Solution
<i>EE-1</i>	RS485 communication fault	①The baud rate setting is incorrect ②The serial port has a communication error due to interference ③The communication is off for a long time	①Adjust the baud rate; ②Check the communication cable and add anti-interference measures; ③Check whether the host computer is working and whether the communication cable is disconnected
<i>EE-4</i>	Keypad communication fault	①The circuit of connecting board and keypad is out of work ②The wires between connecting board and keypad disconnect	①Ask for service ②Check and reconnect it
<i>ERR1</i>	Data upload fault		
<i>ERR2</i>	Data download fault		

6.2 Anomalies and Solutions

Table6–2 Common faults and solutions

Fault	Reason	Solutions
No display after power on	1.Power grid voltage below 2.DC accessory power supply 3. Charging resistor damaged	①Check the voltage of the grid ②Ask for service ③Ask for service
Power trip	1.Short circuit in the inverter's input side 2. Exiguous air switching capacity	1. Check wiring or seek service 2. Expand air switching capacity
Motor doesn't move	1.Incorrect wiring 2.Error setting of operation	1. Check wiring 2. Reset the operation mode

	mode; 3. Overload or motor stalled	3.Reduce loads or regulate motor's status.
Motor reverse	①Error phase sequence of motor wiring	①Swap random two phases of the output terminals U, V and W
Motor cannot accelerate or decelerate normally	①Acc/Dec time setting is improper ②The setting of over-current stall point is low ③Over-voltage stall prevention enabled ④Improper setting of carrier frequency or oscillation occurred ⑤The load is large	①Reset the Acc/Dec time ②Increase the setting value of over-current stall point ③Increase the dec. Time or reduce load inertia ④Reduce the carrier frequency ⑤Lower the load or replace a larger power inverter
Motor's speed fluctuates while at constant speed.	1.Excessive fluctuation of loads 2.Under setting of motor's overload protection coefficient 3. Loose contact of frequency setting potentiometer	1. Reduce load fluctuation 2. Increase overload protection coefficient 3.Replace the potentiometer or seek service

7. Inverter Inspection and Maintenance

7.1 Inspection and Maintenance

The following influences may lead to latent failure of the inverter such as ambient temperature, humidity, dust, vibration, as well as device ageing other causes of the inverter itself during long-period operation on industrial occasions. So it is necessary to perform daily and periodic inspections and maintenance on the inverter.

7.1.1 Daily Inspection Items

Table 7-1 Daily Check List

Target of Inspection	Check cycle Content	Inspection	Inspection Method	Criteria	Measuring Instrument
Operating ambient	• Ambient temperature • Humidity, Dust, corrosive gas, oil mist and etc.	Daily	• Thermo-meter test • Nose Inspection • Visual Inspection	• ambient temperature between -10 to 40°C no-condensing; • Humidity between 20 to 90% no dew or special odor	• Thermo-meter • Hygrometer
Inverter	• Vibration • Heat • Noise	Daily	• Touch the housing; • Hearing check	• Stable vibration • Normal temperature • No abnormal noise	

Motor	• Vibration • Heat • Noise		• Touch the housing • Hearing check	• Stable vibration • Normal temperature • No abnormal noise	
Electric Parameter	• Input voltage • Output voltage • Output current		• Meter test	• Each electric Parameter is within the rated value.	• Moving-iron voltmeter • Rectifier voltmeter • Clamp meter



WARNING

- Make sure that only qualified personnel will perform maintenance. inspection and part replacement to avoid accidents.
- Wait at least 10 minutes after turning OFF the input power supply before performing maintenance or an inspection. Otherwise, there is the danger of electric shock.
- Make sure to open the front panel only after the indicator on the control keypad turns OFF and verify the charging indicator at the right side of main loop terminal is OFF after the panel is opened.
- Do not use an insulated appliance while performing check and do not operate the equipment with wet hand(s) to avoid unexpected accidents.
- Always keep the equipment clean so that dust and other foreign matter does not enter the inverter.
- Keep electronic equipment away from moisture and oil. Dust, steel filings and other foreign matter can damage the inverter, causing unexpected accidents. so do take a special care.

7.1.2 Periodic Inspection Items

Table 7-2 Periodic Inspection Items

Target or Inspection	Inspection Items	Contents of Inspection	Inspection Cycle	Inspection Method	Criteria
Main circuit	Overall	- Check if there is any loose connector or terminal. - Check if there is any device burnt.	Regular	Visual	- No loose connector or loose terminal. - No burnt device
	Main power module	Check if it is damaged or not.	Regular	Visual	No sign of damage..
	Filter capacitor	- Check if there is any leakage. - Check if there is any inflation.	Regular	Visual	- No leakage; - No inflation.
	Relay	- Check if there is any abnormal sound of actuation. - Check if dust has been cleaned.	Regular	- Visual - Hearing check	- Normal sound; - Clean.
Main circuit	Resistor	- Check if there is any big crack. - Check if the color is abnormal.	Regular	Visual	- No crack. - Normal color.
	Fan	Check if there is any abnormal noise	Regular	Visual Audio	Normal sound and stable

		or vibration.			vibration.
	PCB	Check if dust has been cleaned	Regular	Visual	Neat and clean.
Control circuit	FPC strand socket	Check if it is loose.	Regular	Visual	No loose connection.
	Overall	- Check there is any special odor or discoloring. - Check if there is any crack.	Regular	Nose or Visual inspection	- No odor and discoloring; - No crack, smooth surface.
Keyboard	LED	Check if the LED display is normal.	Regular	Visual	Normal and clear
	Connecting cable	- Check if there is any scratch. - Check if it is connected tightly.	Regular	Visual	- No scratched surface. - No loose connection.



WARNING

- Do not remove or shake the device arbitrarily, nor pull out the connector during inspection. Otherwise, this may result in inverter failure or damage.
- Do not leave any inspection tool (ie., a screwdriver) in the machine after periodic check. Otherwise, there is the danger of damage to the inverter.

7.2 Replacement of the Inverter Wearing Parts

The wearing parts of inverter mainly include cooling fan and filter electrolytic capacitor. Usually, a cooling fan's service life is 20,000~30,000 hours and an electrolytic capacitor's service life is 40,000~50,000 hours. User can decide when to replace these parts according to the corresponding operation time.

1. Cooling Fan

It is advisory to replace the fan when abnormal noise or even vibration occurred to the fan due to bearing wear and fan blade aging. The standard replacement age is 2~3 years.

2 Filter Electrolytic Capacitor

The performance of filter electrolytic capacitor is subject to the pulsating current of main circuit. High ambient temperature or frequent load jump may cause damage to the filter electrolytic capacitor. Generally, every 10 °C rise in temperature may lead to reduction of capacitor's service life by half(as shown in Fig.8-1).if there is any electrolytic leakage of safety valve emission. Just replace it at once, the standard replacement age for electrolytic capacitor is 4~5 years




Figure 7-1 Capacitor Life Curve

3. The above replacement duration for inverter's wearing parts is applied to the following conditions:

- Ambient Temperature: 30°C averagely all year round;
- Load Proportion: <85%;
- Operation Time: 12h/day.

If used beyond the above mentioned range, the service life of the inverter's wearing parts will minimize.

7.3 Storage of Inverter

Please pay attention to the following points if an inverter is set aside or stored for a short/long period:

- DO not keep the inverter in a place with high temperature, humidity, heavy dust, and metal shavings, corrosive gas and vibration, and ensure good ventilation.
- Long-term idle of the inverter may cause decreasing in filter characteristic of the electrolytic capacitor. So it should be recharged within half a year and the recharging period should be at least 5 hours.
- DO raise the voltage gradually by using a voltage regulator to some rated value before it is recharged. At the same time, check whether the inverter's function is normal or not, whether there is a short circuit caused by some problems. In case the above problems occur, just remove or seek service as soon as possible.

8.Outline Dimension & Installation Dimension

8.1 Inverter Outline Dimension & Installation Dimension




Fig.8-1 Inverter Outline Schematic Diagram

Inverter Model	Power (KW)	Dimension(MM)						Fig.
		H	H1	W	W1	D	d	
ZVF600-G0R7T2/S2	0.75	193	170	150	140	131	Φ 4.5	Fig. 8-1
ZVF600-G1R5T2/S2	1.5							
ZVF600-G2R2T2/S2	2.2							
ZVF600-G0R7T4	0.75							
ZVF600-G1R5T4	1.5							
ZVF600-G2R2T4	2.2							
ZVF600-G3R0T4	3.0							




Fig.8-2 Inverter Outline Schematic Diagram

Inverter Model	Power (KW)	Dimension(MM)						Fig.
		H	H1	W	W1	D	d	
ZVF600-G3R7T2	3.7	228	205	150	140	131	$\Phi 4.5$	Fig. 8-2
ZVF600-G4R0T4	4.0							
ZVF600-G5R5T4	5.5							
ZVF600-G7R5T4	7.5							

9. Quality Warranty

9.1 Inverter Quality Warranty

1. Warranty Period under Normal Conditions

- We provide guarantees for repair, replacement and return of the purchase in 1 month from the date of use. (excluded the non–stantard inverters.)
- We provide guarantees for repair and replacement in 3 months from the date of use.
- We provide guarantee for repair in 12 months from the date of use.

2. If the date of use can not be verified, then the warranty period shall be 18 months from the date of manufacturer. Service exceeding the warranty period shall be charged to the purchaser. The purchaser enjoys life–long paid service whenever and wherever he Uses an inverter made in our company.

3. Service in the following cases, even within the warranty period, shall be charged to the purchaser:

- Damage caused by mal–operation in violation of this manual;
 - Damage caused by improper use of an inverter that is off technical standard and requirement;
 - Malfunction or damage caused by fire, earthquake, flood, abnormal input voltage or other natural disasters;
 - Artificial damage caused by unauthorized repair or renovation;
 - Induced failure or aging of the device due to poor ambient;
 - Delayed or unsatisfied payment in violation of purchase appointment;
 - Unidentifiable nameplate, mark and date of manufacture
 - Malfunction or damage caused by improper transit or storage after purchase;
 - Fail to give an objective description on the use of installation, wiring, operation, maintenance or else;
 - Defective products should be sent to us for repair, replacement and return, which can be proceeded only after verifying the burden of liability
4. In case there is any quality problem or accident, we merely promise to bear the above–mentioned responsibilities. If a user needs more guarantees for liabilities, please assure on the insurance company voluntarily

Appendix 1: RS485 Communication Protocol

ZVF600-G Series inverter use the popular MODBUS communication protocol under RS485 communication control. It must set the inverter address, communication baud rate, data format by manual , and these parameters couldn't be modified.

Modbus communication use two codes : ASCII (American standard code for information Interchange) and RTU (Remote Terminal Unit). ASCII data to be transferred will be converted into the corresponding ASCII and then transmitted, while the RTU data sucked directly, not through the conversion.

Code Meaning:

ASCII mode:

Each 8-bit data is the combination of two ASCII characters. For example, 0x1F, ASCII shown a "1F" , are made up of "1" (31Hex) , "F" (46Hex) ,The ASCII code 0-9,A-F are as bellows.

Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H

RTU mode:


Each byte of data is the combination of two 4-bit hexadecimal characters.

For example, 0X1F RTU stand for '1FH'.


2. Data Format

2.1 10-bit character frame (For 7-bit character):


(7, N, 2)



(7, E, 1)




(7, O, 1)




11-bit character frame (For 8-bit character):


(8, N, 2)



(8, E, 1)



(8, O, 1)



3.1 Communication Data structures

Communication Data Frame:

ASCII mode:

STX	Start character' : ' (3 AH)
ADR 1	Communication address: 8-bit address consists of 2 ASCII codes
ADR 0	
CMD 1	Command code: 8-bit command code consists of 2 ASCII codes
CMD 0	
DATA (n-1)	Data content: N x 8-bit data consists of 2n ASCII codes, n <=16, maximum of 32 ASCII codes
...	
DATA 0	
LRC CHK 1	LRC check sum: 8-bit check sum consists of 2 ASCII codes
LRC CHK 0	
END 1	END characters: END 1=CR (0DH), END 0= LF (0AH)
END 0	

RTU mode:

START	More than 10ms at resting time or 3.5 bytes transmission time
ADR	Communication address: 8-bit address
CMD	Command code: 8-bit command
DATA (n-1)	Data content: N x 8-bit data , n <=32
.....	
DATA 0	
CRC CHK Low	RC check sum: 16-bit check sum consists of 2 characters of 8-bit
CRC CHK High	
END	More than 10ms at resting time or 3.5 bytes transmission time

ADR (Communication Address)

Valid communication addresses are in the range of 1 to 247. An address equals to 0 , means a broadcast to all AC drives (AMD) in the network. In this case, the inverter will not reply to the master device.

For example, communication to inverter with address 16 decimal:

ASCII mode: (ADR 1, ADR 0) = ' 1' , ' 0' => '1' =31H, '0' =30H

RTU mode: (ADR)=10H

Function (Function code) and DATA (data characters)

The format of data characters depends on the function code. The available function codes are described as follows:

03: read data from register

06: write single data to register

08: loop circuit detection

10: write multiple data to registers

Command code: 03H, read inverter register contents.

For example, reading continuous 2 words from starting address 2102H of inverter with address 01H.

RTU mode:

Command message:

Response message:

Address	01H
Function	03H
Starting address	21H
	02H
Number of data (count by word)	00H
	02H
CRC CHK Low	6FH
CRC CHK High	F7H

Address	01H
Function	03H
Number of data (count by byte)	04H
Content of data address 2102H	17H
	70H
Content of data address 2103H	00H
	00H
CRC CHK Low	FEH
CRC CHK High	5CH

ASCII mode:

Command message:

STX	'.'
Address	'0'
	'1'
Function	'0'
	'3'
Starting address	'2'
	'1'
	'0'
	'2'
Number of data (count by word)	'0'
	'0'
	'0'
	'2'
LRC Check	'D'
	'7'
END	CR
	LF

Response message:

STX	'.'
Address	'0'
	'1'
Function	'0'
	'3'
Number of data (count by byte)	'0'
	'4'
Content of starting address 2102H	'1'
	'7'
	'7'
Content of address 2103H	'0'
	'0'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

Command code: 06H, write a word to the inverter register

For example, write 6000(1770H) to address 0100H of inverter with address 01H.

RTU mode:

Command message:

Address	01H
Function	06H
Data address	01H
	00H
Data content	17H
	70H
CRC CHK Low	86H
CRC CHK High	22H

Response message:

Address	01H
Function	06H
Data address	01H
	00H
Data content	17H
	70H
CRC CHK Low	86H
CRC CHK High	22H

ASCII Mode:

Command message:

STX	'.'
Address	'0'
	'1'
Function	'0'
	'6'
Data address	'0'
	'1'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

Response message:

STX	'.'
Address	'0'
	'1'
Function	'0'
	'6'
Data address	'0'
	'1'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

Command code: 08H, communication loop circuit detection

It's used to test the communication between the master (usually PC or PLC) and inverter is normal or not. The inverter will send the received data to the master.

RTU Mode:

Command message

Address	01H
Function	08H
Data address	00H
	00H
Data content	17H
	70H
CRC CHK Low	EEH
CRC CHK High	1FH

Response message:

Address	01H
Function	08H
Data address	00H
	00H
Data content	17H
	70H
CRC CHK Low	EEH
CRC CHK High	1FH

ASCII mode:

Command message:

STX	'.'
Address	'0'
	'1'
Function	'0'
	'8'
Data address	'0'
	'0'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'0'
END	CR
	LF

Response message:

STX	'.'
Address	'0'
	'1'
Function	'0'
	'8'
Data address	'0'
	'0'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'0'
END	CR
	LF

Command code: 10H, write multiple data to registers

For example: Write 5000(1338H). 4000 (0FA0H) to the address 0500H and 0501H of the inverter with address 01H.

RTU Mode:

Command message:

Address	01H
Function	10H
Data address	05H
	00H
Number of data (count by word)	00H
	02H
Number of data (count by byte)	04H
The first data content	13H
	88H
The second data content	0FH
	A0H
CRC CHK Low	4DH
CRC CHK High	D9H

Response message:

Address	01H
Function	10H
Starting data address	05H
	00H
Number of data (count by word)	00H
	02H
CRC CHK Low	41H
CRC CHK High	04H

ASCII mode:

Command message:

STX	‘.’
Address	‘0’
	‘1’
Function	‘1’
	‘0’
Starting data address	‘0’
	‘5’
	‘0’
	‘0’
Number of data (count by word)	‘0’
	‘0’
	‘0’
	‘2’
Number of data (count by byte)	‘0’
	‘4’
The first data content	‘1’
	‘3’
	‘8’
	‘8’
The second data content	‘0’
	‘F’
	‘A’
	‘0’
LRC Check	‘9’
	‘A’
END	CR
	LF

Response message

STX	‘.’
Address	‘0’
	‘1’
Function	‘1’
	‘0’
Data address	‘0’
	‘5’
	‘0’
	‘0’
Number of data (count by word)	‘0’
	‘0’
	‘0’
	‘2’
LRC Check	‘E’
	‘8’
END	CR
	LF

3.5 CHK (check sum)

ASCII mode:

ASCII mode adopt LRC (Longitudinal Redundancy Check) check sum. The LRC check sum is ADR1 to the last data content and the results is 256 as one unit. the excess parts removes, (For example, the receiving results is hexadecimal 128H only take 28H), Then calculate the two times complement and the getting result is LRC check sum.

For example, the first example of inquiry information check sum: 01H +03 H +21 H+ 02 H+00 H+02 H = 29H, and then take 2's complement = D7H.

RTU mode:

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: the first byte of the command message and 16-bit CRC make low byte XOR arithmetic.

Step 3: Shift the CRC register one bit to the right with MSB zero filling. Extract and examine the LSB.

Step 4: If the LSB of CRCregister is 0, repeat step 3, else XOR or the CRC register with the polynomial value A001H.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

Step 6: Repeat steps 2 to 5 for the next 8-bit byte of the command message.

Continue doing this until all bytes have been processed. The final contents of the CRC register is the CRC value.

When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char* data ←a pointer to the message

Unsigned char length ←the quantity of bytes in the message.

The function returns the CRC value as a type of unsigned int.

```

unsigned int crc_chk(unsigned char* data, unsigned char length)
{
    int j;
    unsigned int reg_crc=0xFFFF;
    while(length--)
    {
        reg_crc ^= *data++;
        for(j=0;j<8;j++)
        {
            if(reg_crc & 0x01) /* LSB(b0)=1 */
            {
                reg_crc=(reg_crc>>1) ^ 0xA001;
            }
            else
            {
                reg_crc=reg_crc >>1;
            }
        }
        return reg_crc;
    }
}

```

The definition of the communication data address

The communication data address is used to control the operation of the inverter, get the state information and the rated function parameter setting.

The serial number of the function code is corresponding to the register address, but it should convert to hexadecimal number (except group parameters, as they are hexadecimal number), For example , FA.12 hexadecimal number express the function address is 0A0CH.

In addition, the EEPROM are frequently stored , will reduce the life of the EEPROM , For the users , No need to store for some function code in the mode of communication. Only change the value of RAM to meet the requirements.

To realize this function, you only need to turn the top digit of the function code address from 0 to 1. For example . the function code F0.07 only modify the RAM value instead of storing it in the EEPROM. and can set the address set to 8007H. this address only use for writing on chip RAM. which can not do the read function . It's will be invalid address if read.

3.6 The definition of the communication parameter address

Address list:

Parameter Description	Address	Function Description		W/R Feature
Inverter setting parameter	Fx.xxH	x.xx stand for parameter number. For example F5.05 expressed by 0505H .		
Control command	1000H	0001H	Forward running	W/R
		0002H	Reverserunning	
		0003H	Jog forward	
		0004H	Jog reverse	
		0005H	Stop	
		0006H	Coast to stop	
		0007H	Reset fault	
		0008H	Jog stop	
Monitor state	1001H	0001H	Forward running	R
		0002H	Reverse running	
		0003H	Standby	
		0004H	Fault	
Communication setting value	2000H	Communication Setting Range (-10000~10000) Note: the communication setting is the percentage of the relative value(-100.00%~100.00%). can be communication writing operation . If it is set as frequency source, the value is the percentage of maximum frequency (F0.04). If it is set as torque given ,the corresponding is the percentage of the torque upper limit (F3.07). If it is set as PID settingvalue or feedback value, the value is the percentage of the PID.		W/R

Monitor parameter	3000H	Running frequency	R
	3001H	Setting frequency	R
	3002H	Output current	R
	3003H	Output voltage	R
	3004H	Output rotation speed	R
	3005H	Output power	R
	3006H	Output torque	R
	3007H	DC bus voltage	R
	3008H	PID setting value	R
	3009H	PID feedback value	R
	300AH	Input terminal state	R
	300BH	Output terminal state	R
	300CH	Analog AVI value	R
	300DH	Analog ACI value	R
Inverter fault address	5000H	See the attached fig 3-1	R
Communication fault address	5001H	See the attached fig 3-2	R

Appendix Table:1-1 Data and fault type in 5000H

Data	Fault Type	Data	Fault Type
00H	No fault	0CH	Motor overload(OL1)
01H	Over-current when acceleration(ocA)	0DH	Inverter overload (OL2)
02H	Over-current when deceleration(ocd)	0EH	External fault(EF)
03H	Overcurrent when constant speed running(ocn)	0FH	RS485 communication fault (CE-1)
04H	Overvoltage when acceleration(ovA)	10H	Reserved
05H	Overvoltage when deceleration(ovd)	11H	Current detection fault(iTE)
06H	Overvoltage when constant speed running (ovn)	12H	Keypad communication fault (CE-4)
07H	Overvoltage when stop (ovS)	13H	Motor auto tuning fault(tE)
08H	DC bus under voltage fault (Lv)	14H	EEPROM operation fault(EEP)
09H	Output phase loss(LP)	15H	PID feedback fault (PIDE)
0AH	Output shortcircuit(SC)	16H-1BH	Reserved
0BH	Over-heat (OH1)	1CH	Output phase loss (SPO)

Additional response to error communication:

When the inverter are communication connection. The inverter will response to the error code if the error caused, and the maximum unit (bit 7) of the command code set to 1 (Function code and 80H) and answer to the Master. The master will know there will be error.

ASCII mode

STX	‘:’
Address	‘0’
	‘1’
Function	‘8’
	‘6’
Fault address	‘5’
	‘0’
	‘0’
	‘1’
Fault code	‘0’
	‘1’
LRC Check	‘2’
	‘7’
END	CR
	LF

RTU mode

Address	01H
Function	86H
Fault address	50H
	01H
Fault code	01H
CRC CHK Low	F0H
CRC CHK High	C9H

Appendix Table :1-2 Data and fault type in 5001H

Communication fault address	5001H	00H	No fault
		01H	Command code error
		02H	Illegal address
		03H	Illegal data
		04H~ 05H	Reserved
		06H	Inverter is busy
		07H~ 09H	Reserved
		10H	Password error
		11H	Check error
		12H	Invalid modified parameters
		13H	System locked
		14H	Illegal of data number

Appendix 2: Selection List of Peripheral Appliances

Inverter model	Brake Switch Capacity (A)	Main Circuit (mm ²)		Control Wire (mm ²)
		Input Wire	Output Wire	
ZVF600-G0R7T2/S2	10/20	2.5	2.5	0.75
ZVF600-G1R5T2/S2	10/20	2.5	2.5	0.75
ZVF600-G2R2T2/S2	16/32	4	4	0.75
ZVF600-G3R7T2/S2	25	4	4	0.75
ZVF600-G0R7T4	6	2.5	2.5	0.75
ZVF600-G1R5T4	6	2.5	2.5	0.75
ZVF600-G2R2T4	10	2.5	2.5	0.75
ZVF600-G3R0T4	10	4	4	0.75
ZVF600-G4R0T4	16	4	4	0.75
ZVF600-G5R5T4	20	6	6	0.75
ZVF600-G7R5T4	25	6	6	0.75

Appendix 3: Inverter User' s Warranty Bill

User's details

Company Name		Phone	
Add		Post Code	
Contact Person		Department	

Name of Distributor		The date of Purchase	
Inverter Model		Serial Number	
Equipment Name		Motor Power	
The date of Installation		The date of begin use	

Records of repair

Fault :	
Solution:	
The date of repair:	The name of repair workers:



TIP

The user should keep this warranty bill .

