




GSW-N32/4

Enclosure DC Isolator


Instructions for installation and operation

- Be sure number (1,3,5,7) on switch and "IP66NW" on cover are not inverted
- Rotate Handel to the "OFF" position and locate shaft into switch body.
- Tighten screw 1,3,2,4 IN THAT ORDER.
- Make sure that number(5) is assembled on cover




The switch with a box is suitable for outdoor use, lthe solar at 40°C=32A, lthe solar at 60°C=29A
Please note that all connections (including bridging link connections) should be tightening before energization.

DC Switch Disconnecter for Photovoltaics Wiring diagram



Switch examples



Cable cross sections

Rigid(Stranded or solid)	
	4-16mm ² , AWG 11-5
	4-10mm ² , AWG 11-7

Screwdriver, Tightening torque



Mounting Type	Enclosure(IP66NW)	Vertically or Horizontally
	Switch body(IP20)	Vertically ↑↑